

Last Modified: 7-13-2007	1.7 T
Service Category: Vehicle Interior	Section: Heating/Air Conditioning
Model Year: 2008	Model: ES350 Doc ID: RM000001M2W00RX
Title: AIR CONDITIONING: AIR CONDITIONING SYSTEM: PROBLEM SYMPTOMS TABLE (2008 ES350)	

## PROBLEM SYMPTOMS TABLE

## AIR CONDITIONER:

Temperature Control: No cool air comes out	7. Air mix control servo motor circuit (Driver side) 8. Air mix control servo motor circuit (Passenger side) 9. Evaporator temperature sensor circuit 10. Room temperature sensor circuit 11. Ambient temperature sensor circuit 12. Heater control panel power source circuit 13. LIN communication circuit 14. Expansion valve 15. A/C control assembly 16. A/C amplifier 17. ECM	INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO
Temperature Control: No warm air comes out	1. Air mix control servo motor circuit (Driver side) 2. Air mix control servo motor circuit (Passenger side) 3. Evaporator temperature sensor circuit 4. Room temperature sensor circuit 5. Ambient temperature sensor circuit 6. A/C amplifier	INFO INFO INFO INFO INFO INFO
Temperature Control: Output air is warmer or cooler than the set temperature or response is slow	1. Refrigerant volume 2. Refrigerant pressure 3. Solar sensor circuit (Driver side) 4. Solar sensor circuit (Passenger side) 5. Room temperature sensor circuit 6. Ambient temperature sensor circuit 7. Air mix control servo motor circuit (Driver side) 8. Air mix control servo motor circuit (Passenger side) 9. Radiator unit sub-assembly 10. Expansion valve 11. A/C amplifier	INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO INFO
	1. Air mix control servo motor circuit (Driver side) 2. Air mix control servo motor circuit	INFO INFO

	(Passenger side)	
Temperature Control: No temperature control (only Max. cool or Max. warm)	3. Room temperature sensor circuit	INFO
	4. Ambient temperature sensor circuit	INFO
	5. Evaporator temperature sensor circuit	INFO
	6. Solar sensor circuit (Driver side)	INFO
	7. Solar sensor circuit (Passenger side)	INFO
	8. A/C control assembly	INFO
	9. A/C amplifier	INFO
No air inlet control	1. Air inlet control servo motor circuit	INFO
	2. A/C amplifier	INFO
No air flow mode control	1. Air outlet control servo motor circuit	INFO
	2. A/C amplifier	INFO
Engine idle up does not occur, or is continuous	1. Air conditioning compressor magnetic clutch circuit	INFO
	2. Compressor lock sensor circuit	INFO
	3. Compressor solenoid circuit	INFO
	4. Heater control panel power source circuit	INFO
	5. LIN communication circuit	INFO
	6. A/C control assembly	INFO
	7. A/C amplifier	INFO
	8. ECM	INFO
Blinking of A/C indicator	1. Compressor solenoid circuit	INFO
	2. A/C amplifier	INFO
Diagnostic trouble codes are not recorded. Set mode is cleared when engine switch is turned off.	1. Back-up power source circuit	INFO
	2. A/C amplifier	INFO

