


<b>DTC</b>	<b>C1268/68</b>	<b>L4 SIGNAL PICKUP MALFUNCTION</b>
------------	-----------------	-------------------------------------

### CIRCUIT DESCRIPTION

After confirming that the transfer is in the L4 position, A-TRAC and DAC will be activated according to the vehicle conditions (see page 05-720).

DTC No.	DTC Detection Condition	Trouble Area
C1268/68	The L4 signal input to the ECU does not match the L4 signal output from the ECM	<ul style="list-style-type: none"> <li>• Transfer indicator (L4) switch</li> <li>• Transfer indicator (L4) switch circuit</li> </ul>

### WIRING DIAGRAM



## INSPECTION PROCEDURE


### NOTICE:

When replacing the master cylinder solenoid, perform zero point calibration (see page 05-734).

### 1 INSPECT SKID CONTROL ECU (EXI4 TERMINAL VOLTAGE)

#### Skid Control ECU (Wire Harness Side)

#### Connector Front View:



- Disconnect the skid control ECU connector.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

#### Standard:

Tester Connection	Condition	Specified Condition
S37-21 (EXI4) - Body ground	Transfer indicator switch ON (Shift L4 position)	Below 1.5 V
S37-21 (EXI4) - Body ground	Transfer indicator switch OFF (Any shift position except L4)	8 to 14 V

**NG** → Go to step 4

**OK**

### 2 PERFORM TEST MODE (SIGNAL CHECK) (SEE PAGE 05-738)

- Reconnect the skid control ECU connector.
- Check test mode (signal check) DTC is detected.

#### Result:

Test mode (signal check) DTC is output	A
Test mode (signal check) DTC is not output (When troubleshooting in accordance with the DTC CHART.)	B
Test mode (signal check) DTC is not output (When troubleshooting in accordance with the PROBLEM SYMPTOMS TABLE.)	C

**B** → REPAIR OR REPLACE HARNESS OR CONNECTOR (L4 CIRCUIT)

**C** → PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-750)

**A**

**3 RECONFIRM DTC**

- (a) Clear the DTC (see page 05-757).
- (b) Check if the same DTC is detected (see page 05-757).

HINT:

Reinstall the sensors, connectors, etc. and restore the previous vehicle conditions before rechecking for DTCs.

**Result:**


DTC is output	A
DTC is not output	B

**B** → **END**

**A**

**REPLACE MASTER CYLINDER SOLENOID (SEE PAGE 32-23)**

**4 INSPECT TRANSFER INDICATOR SWITCH**



- (a) Disconnect the transfer indicator (L4) switch connector.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**


Tester Connection	Condition	Specified Condition
D1-1 - D1-2	Switch pin pushed in	Below 1 Ω
D1-1 - D1-2	Switch pin free	10 kΩ or higher

**NG** → **REPLACE TRANSFER INDICATOR SWITCH**


**OK**

**5 CHECK HARNESS AND CONNECTOR (BETWEEN SKID CONTROL ECU, BODY GROUND AND TRANSFER INDICATOR SWITCH) (SEE PAGE 01-36)**

**Skid Control ECU (Wire Harness Side)  
Connector Front View:**



**Transfer Indicator (L4) Switch (Wire Harness Side)  
Connector Front View:**



F49362  
I44031

I45333

(a) Measure the resistance according to the value(s) in the table below.


**Standard:**

Tester Connection	Specified Condition
S37-21 (EXI4) - D1-1	Below 1 Ω
S37-21 (EXI4) - Body ground	10 kΩ or higher
D1-2 - Body ground	Below 1 Ω

**NG REPAIR OR REPLACE HARNESS OR CONNECTOR (EXI4 CIRCUIT)**

**OK**

**6 CHECK HARNESS AND CONNECTOR (BETWEEN ECM AND TRANSFER INDICATOR SWITCH) (SEE PAGE 01-36)**



- (a) Disconnect the ECM connector.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition
E7-13 (L4) - D1-1	Below 1 Ω
E7-13 (L4) - Body ground	10 kΩ or higher

**Result:**

OK (When troubleshooting in accordance with the DTC CHART.)	A
OK (When troubleshooting in accordance with the PROBLEM SYMPTOMS TABLE.)	B
NG	C

**B** → PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-750)

**C** → REPAIR OR REPLACE HARNESS OR CONNECTOR

**A**

**END**