


|            |                 |  |
|------------|-----------------|--|
| <b>DTC</b> | <b>C2171/71</b> | <b>TRANSMITTER ID NOT REGISTERED(MAIN)</b> |
|------------|-----------------|--|

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>C2172/72</b> | <b>TRANSMITTER ID NOT REGISTERED(2ND)</b> |
|------------|-----------------|---|

**CIRCUIT DESCRIPTION**

| DTC No.              | DTC Detecting Condition   | Trouble Area  |
|----------------------|---|---|
| C2171/71<br>C2172/72 | Transmitter ID code is not registered.<br>(When an ID code is unregistered for 51 minutes or more.) | <ul style="list-style-type: none"> <li>• Tire pressure monitor ECU</li> <li>• Tire pressure warning switch</li> <li>• Wire harness</li> </ul> |

**WIRING DIAGRAM**



**INSPECTION PROCEDURE**

HINT:

Set the tire pressure to the specified value.

|          |   |
|----------|---|
| <b>1</b> | <b>CHECK TIRE PRESSURE WARNING LAMP</b> |
|----------|---|

(a) Check the tire pressure warning lamp.

**Result:**

|   |  |
|---|--|
| A | Does not blink   |
| B | Comes on and goes off repeatedly at 0.5 second intervals |

|          |                     |
|----------|---------------------|
| <b>B</b> | <b>Go to step 4</b> |
|----------|---------------------|

**A**

|          |                                    |
|----------|------------------------------------|
| <b>2</b> | <b>CLEAR DTC (SEE PAGE 05-654)</b> |
|----------|------------------------------------|

**3 CHECK DTC**

- (a) Check for DTC.  
OK: DTC is not output.

NG → REPLACE TIRE PRESSURE MONITOR ECU  
(SEE PAGE 28-9)

OK

END (Perform procedures to check if the transmitter ID is registered (see page 05-642).)

**4 CHECK DTC**

- (a) Check if DTC C2171/71 is output.

NO → Go to step 9

YES

**5 CHECK TIRE PRESSURE WARNING SWITCH MAIN POSITION**

OK:  
Tire pressure warning switch is set to "MAIN".

HINT:


If the tire pressure warning switch is not set to "MAIN", set the tire pressure warning switch to the "MAIN" and go to step 1.

NG → Go to step 1

OK

**6 INSPECT TIRE PRESSURE MONITOR ECU**

Tire Pressure Monitor ECU:



- (a) Connect the tire pressure monitor ECU T15 connector.  
(b) Measure the voltage according to the value(s) in the table below.

Standard:

| Tester Connection           | Specified Condition |
|-----------------------------|---------------------|
| T15-9 (IDSW) - T15-11 (GND) | 10 V or higher      |


NG → Go to step 7

OK

REGISTRATION OF TRANSMITTER ID (SEE PAGE 05-642)

## 7 CHECK HARNESS AND CONNECTOR(TIRE PRESSURE MONITOR ECU - TIRE PRESSURE WARNING SWITCH) (SEE PAGE 01-36)

### Tire Pressure Monitor ECU:




- Disconnect the tire pressure monitor ECU T15 connector and tire pressure warning switch T16 connector.
- Measure the resistance according to the value(s) in the table below.

#### Standard:

| Tester Connection          | Specified Condition     |
|----------------------------|-------------------------|
| T15-9 (IDSW) - T16-2       | Below 1 $\Omega$        |
| T15-9 (IDSW) - Body ground | 10 k $\Omega$ or higher |

### Tire Pressure Warning Switch:




NG

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

## 8 INSPECT TIRE PRESSURE WARNING SWITCH

### Tire Pressure Warning Switch:



- Disconnect tire pressure warning switch T16 connector.
- Measure the resistance according to the value(s) in the table below.

#### Standard:

| Switch Position | Tester Connection | Specified Condition     |
|-----------------|-------------------|-------------------------|
| MAIN            | 2 (INT) - 1 (E)   | 10 k $\Omega$ or higher |
| 2nd             | 2 (INT) - 1 (E)   | Below 1 $\Omega$        |

NG

**REPLACE TIRE PRESSURE WARNING SWITCH**

OK

**REPLACE TIRE PRESSURE MONITOR ECU (SEE PAGE 28-9)**

**9 CHECK TIRE PRESSURE WARNING SWITCH 2ND POSITION**

**OK:**

Tire pressure warning switch is set to "2nd".


**HINT:**

If the tire pressure warning switch is not set to "2nd", set the tire pressure warning switch to the "2nd" and go to step 1.

**NG** Go to step 1

**OK**

**10 INSPECT TIRE PRESSURE MONITOR ECU**



- (a) Connect the tire pressure monitor ECU T15 connector.
- (b) Measure the voltage according to the value(s) in the table below.

**Standard:**

| Tester Connection           | Specified Condition |
|-----------------------------|---------------------|
| T15-9 (IDSW) - T15-11 (GND) | Below 6 V           |


**NG** Go to step 11

**OK**

**REGISTRATION OF TRANSMITTER ID (SEE PAGE 05-642)**

## 11 CHECK HARNESS AND CONNECTOR(TIRE PRESSURE MONITOR ECU - TIRE PRESSURE WARNING SWITCH) (SEE PAGE 01-36)

### Tire Pressure Monitor ECU:




- Disconnect the tire pressure monitor ECU T15 connector and tire pressure warning switch T16 connector.
- Measure the resistance according to the value(s) in the table below.

#### Standard:

| Tester Connection          | Specified Condition     |
|----------------------------|-------------------------|
| T15-9 (IDSW) - T16-2       | Below 1 $\Omega$        |
| T15-9 (IDSW) - Body ground | 10 k $\Omega$ or higher |

### Tire Pressure Warning Switch:




NG

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

## 12 INSPECT TIRE PRESSURE WARNING SWITCH

### Tire Pressure Warning Switch:



- Disconnect tire pressure warning switch T16 connector.
- Measure the resistance according to the value(s) in the table below.

#### Standard:

| Switch Position | Tester Connection | Specified Condition     |
|-----------------|-------------------|-------------------------|
| MAIN            | 2 (INT) - 1 (E)   | 10 k $\Omega$ or higher |
| 2nd             | 2 (INT) - 1 (E)   | Below 1 $\Omega$        |

NG

**REPLACE TIRE PRESSURE WARNING SWITCH**

OK

**REPLACE TIRE PRESSURE MONITOR ECU (SEE PAGE 28-9)**