

3

**CHECK HARNESS AND CONNECTOR(HEIGHT CONTROL SOLENOID VALVE OR EXHAUST SOLENOID VALVE – SUSPENSION CONTROL ECU)**

- (a) Check for open and short circuit in the harness and the connectors between height control solenoid valve or the exhaust solenoid valve and the suspension control ECU (See page [01-36](#)).

NG

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

**CHECK AND REPLACE SUSPENSION CONTROL ECU (See page [01-36](#))**