

EGR VALVE > INSPECTION

for Preparation [Click here](#)

1. INSPECT EGR VALVE ASSEMBLY

a. Check the resistance of the EGR valve.

i. Measure the resistance according to the value(s) in the table below.

Standard Resistance:

Tester Connection	Condition	Specified Condition
1 - 2	20°C (68°F)	18 to 22 Ω
2 - 3		
4 - 5		
5 - 6		

Text in Illustration

*a	Component without harness connected (EGR Valve)
----	---

If the result is not as specified, replace the EGR valve assembly.



