

DTC	75	Height Control Sensor Circuit
------------	-----------	--------------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
75	Detect uneven ground	<ul style="list-style-type: none"> • Parking on uneven ground (normal) • Height control sensor link • Height control sensor • ECU

When the ECU stores DTC 75 in memory, vehicle height control is not carried out until a normal signal is input to the ECU from the height control sensor.

However, control is resumed if the ignition switch is turned off, then on again.

INSPECTION PROCEDURE

1	Does parking on uneven ground?
----------	---------------------------------------

YES

Transfer the vehicle.

NO

2	Does malfunction disappear by adjusting height control sensor link? (See page SA-125)
----------	--

YES

Adjust height control sensor link.

NO

3	Check and repair or replace parts of the malfunction causes.
----------	---

- (a) Height control sensor malfunction
- (b) ECU malfunction