


# T<sub>D</sub> Terminal Circuit

## CIRCUIT DESCRIPTION


By connecting terminals T<sub>D</sub> and E<sub>1</sub> of the DLC2, the vehicle height control is not carried out.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

1	Check voltage between terminals T <sub>D</sub> and E <sub>1</sub> of DLC2.
---	--



### PREPARATION:

Turn the ignition switch ON.

### CHECK:

Measure the voltage between terminals T<sub>D</sub> and E<sub>1</sub> of DLC2.

### OK:

Voltage: 9 – 14 Ω

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-247](#)).

NG

- |          |   |
|----------|---|
| <b>2</b> | <b>Check for open in harness and connectors between terminals E<sub>1</sub> of DLC2 and body ground (See page <a href="#">IN-30</a>).</b> |
|----------|---|

**NG**

**Repair or replace harness or connector.**

**OK**

- |          |   |
|----------|---|
| <b>3</b> | <b>Check harness and connectors between suspension ECU and DLC2 (See page <a href="#">IN-30</a>).</b> |
|----------|---|

**NG**

**Repair or replace harness or connector.**

**OK**

**Check and replace suspension ECU.**