


Tc Terminal Circuit

CIRCUIT DESCRIPTION

By connecting terminals Tc and E₁ of the DLC1 or DLC2, the DTCs stored in the ECU memory can be displayed by the height control indicator light.


WIRING DIAGRAM



F03460

INSPECTION PROCEDURE

- 1 Check voltage between terminals Tc and E₁ of DLC1 or DLC2.

**PREPARATION:**

Turn the ignition switch ON.

CHECK:

Measure the voltage between terminals Tc and E₁ of DLC1 or DLC2.

OK:

Voltage: 9 - 14 V

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-247](#)).

NG

- 2 Check for open in harness and connectors between terminals E₁ of DLC1 or DLC2 and body ground (See page [IN-30](#)).

NG

Repair or replace harness or connector.

OK

- 3 Check harness and connectors between suspension ECU and DLC1 or DLC2 (See page [IN-30](#)).

NG

Repair or replace harness or connector.

OK

Check and replace suspension ECU.