

| | | |
|------------|-------------------|------------------------------------|
| DTC | 91, 92, 93 | Acceleration Sensor Circuit |
|------------|-------------------|------------------------------------|

CIRCUIT DESCRIPTION

See page [DI-252](#).

| DTC No. | DTC Detecting Condition | Trouble Area |
|----------------|---|---|
| 91 92 93 | The acceleration sensor continues to detect vertical acceleration | <ul style="list-style-type: none"> • Harness or connectors between ECU and acceleration sensor • Acceleration sensor • ECU |

- Code 91 corresponds to the front RH acceleration sensor circuit.
- Code 92 corresponds to the front LH acceleration sensor circuit.
- Code 93 corresponds to the rear RH acceleration sensor circuit.

WIRING DIAGRAM

See page [DI-252](#).

INSPECTION PROCEDURE

HINT:

- When DTC 91 is displayed, check front RH acceleration sensor circuit.
- When DTC 92 is displayed, check front LH acceleration sensor circuit.
- When DTC 93 is displayed, check rear RH acceleration sensor circuit.

See page [DI-252](#).