



INSPECTION

INSPECT FUEL PUMP RESISTOR

Using an ohmmeter, measure the resistance between the terminals.

Resistance:

0.70 – 0.76 Ω at 20°C (68°F)

If the resistance is not as specified, replace the resistor.