


REAR BLOWER MOTOR CIRCUIT

CIRCUIT DESCRIPTION


The luggage room J/B ECU requests the rear A/C amplifier to operate the rear blower motor and controls its operation via the rear blower resistor in this circuit.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT LUGGAGE ROOM J/B ECU(RHR, RFR - BODY GROUND)




- (a) Remove the luggage room J/B with connectors still connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
L13-18 (RHR) - Body ground	Rear blower switch to OFF position	Below 1 V
L13-18 (RHR) - Body ground	Rear blower switch to LO position	10 to 14 V
L13-18 (RHR) - Body ground	Rear blower switch to HI position	10 to 14 V
L13-19 (RFR) - Body ground	Rear blower switch to OFF position	Below 1 V
L13-19 (RFR) - Body ground	Rear blower switch to LO position	Below 1 V
L13-19 (RFR) - Body ground	Rear blower switch to HI position	10 to 14 V

NG**Go to step 2****OK****Go to step 4**

2 INSPECT REAR AIR CONDITIONING AMPLIFIER (RHR, RFR1)



- (a) Remove the A/C amplifier with connectors still connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.


Standard:

Tester connection	Condition	Specified condition
A48-16 (RHR) - Body ground	Rear blower switch to OFF position	Below 1 V
A48-16 (RHR) - Body ground	Rear blower switch to LO position	10 to 14 V
A48-16 (RHR) - Body ground	Rear blower switch to HI position	10 to 14 V
A48-15 (RFR1) - Body ground	Rear blower switch to OFF position	Below 1 V
A48-15 (RFR1) - Body ground	Rear blower switch to LO position	Below 1 V
A48-15 (RFR1) - Body ground	Rear blower switch to HI position	10 to 14 V

NG Go to step 4

OK

3 CHECK HARNESS AND CONNECTOR (LUGGAGE ROOM J/B - REAR AIR CONDITIONING AMPLIFIER) (SEE PAGE 01-44)



- (a) Measure the resistance according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
RHR (L13-18) - RHR (A48-16)	Always	Below 1 Ω
RHR (L13-18) - Body ground	Always	10 kΩ or higher
RFR (L13-19) - RFR1 (A48-15)	Always	Below 1 Ω
RFR (L13-19) - Body ground	Always	10 kΩ or higher

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE LUGGAGE ROOM J/B

4 INSPECT REAR AIR CONDITIONING AMPLIFIER(RHI, RLO, RSLO)



- (a) Remove the rear A/C amplifier with connectors still connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
A48-8 (RHI) - Body ground	Rear blower switch to OFF position	Below 1 V
A48-8 (RHI) - Body ground	Rear blower switch to LO position	10 to 14 V
A48-8 (RHI) - Body ground	Rear blower switch to HI position	10 to 14 V
A48-1 (RLO) - Body ground	Rear blower switch to OFF position	Below 1 V
A48-1 (RLO) - Body ground	Rear blower switch to LO position	Below 1 V
A48-1 (RLO) - Body ground	Rear blower switch to HI position	10 to 14 V
A48-2 (RSLO) - Body ground	Rear blower switch to OFF position	Below 1 V
A48-2 (RSLO) - Body ground	Rear blower switch to LO position	10 to 14 V
A48-2 (RSLO) - Body ground	Rear blower switch to HI position	Below 1 V

NG → Go to step 5

OK

Go to step 7

5 INSPECT REAR BLOWER RESISTOR



- (a) Remove the rear blower resistor.
- (b) Measure the resistance according to the value(s) in the table below.


Standard:

Tester connection	Condition	Specified condition
R33-1 - R33-3	Always	5.2 to 6.0 Ω
R33-2 - R33-3	Always	10.5 to 12.1 Ω

NG → REPLACE BLOWER RESISTOR

OK

6 CHECK HARNESS AND CONNECTOR (AIR CONDITIONING AMPLIFIER - BLOWER RESISTOR) (SEE PAGE 01-44)



(a) Measure the resistance according to the value(s) in the table below.


Standard:

Tester connection	Condition	Specified condition
A48-1 (RLO) - R33-1	Always	Below 1 Ω
A48-1 (RLO) - Body ground	Always	10 kΩ or higher
A48-2 (RSLO) - R33-3	Always	Below 1 Ω
A48-2 (RSLO) - Body ground	Always	10 kΩ or higher
A48-8 (RHI) - R33-2	Always	Below 1 Ω
A48-8 (RHI) - Body ground	Always	10 kΩ or higher
A48-8 (RHI) - R32-1 (+)	Always	Below 1 Ω
A48-6 (GND) - R32-2 (GND)	Always	Below 1 Ω
A48-6 (GND) - Body ground	Always	Below 1 Ω

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

7 INSPECT REAR BLOWER MOTOR



- (a) Remove the blower motor.
- (b) Connect the positive (+) lead to terminal 1 of the blower motor connector and negative (-) lead to terminal 3.


OK:

Blower motor operates smoothly.

NG REPLACE BLOWER MOTOR

OK

**8 CHECK HARNESS AND CONNECTOR (BLOWER MOTOR - BLOWER RESISTOR)
(SEE PAGE 01-44)**



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
R32-1 (+) - R33-2	Always	Below 1 Ω
R32-1 (+) - Body Ground	Always	10 kΩ or higher
R32-2 (GND) - Body Ground	Always	Below 1 Ω

NG REPLACE OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE REAR AIR CONDITIONING AMPLIFIER (SEE PAGE 55-57)