

Last Modified: 7-25-2017	6.8:8.0.51	Doc ID: RM000002P5H000X
Model Year Start: 2007	Model: LS460	Prod Date Range: [09/2006 -]
Title: SUSPENSION: FRONT WHEEL ALIGNMENT: ADJUSTMENT; 2007 MY LS460 [09/2006 -]		

ADJUSTMENT

1. INSPECT TIRES INFO

2. MEASURE VEHICLE HEIGHT (w/o Air Suspension)

- (a) Bounce the vehicle at the corners up and down to stabilize the suspension and inspect the vehicle height.

Standard vehicle height:

-	FRONT (A - B)	REAR (D - C)
Standard Body 18 in. Wheel	91 mm (3.583 in.)	76 mm (2.992 in.)
Standard Body 19 in. Wheel	91 mm (3.583 in.)	76 mm (2.992 in.)
Long Body 18 in. Wheel	91 mm (3.583 in.)	76 mm (2.992 in.)
Long Body 19 in. Wheel	91 mm (3.583 in.)	76 mm (2.992 in.)

Measuring points:

A

Ground clearance of front wheel center

B

Ground clearance of front center position of front No. 2 suspension lower arm assembly front bush installation

C

Ground clearance of pit center of the attachment rear suspension arm


D

Ground clearance of rear wheel center

NOTICE:

Before inspecting the wheel alignment, adjust the vehicle height to the specified value.

If the vehicle height is not as specified, adjust the height by pressing down on the vehicle several times to stabilize the suspension.



3. MEASURE VEHICLE HEIGHT (w/ Air Suspension)

- (a) Bounce the vehicle at the corners up and down to stabilize the suspension and inspect the vehicle height.

Standard vehicle height:

-	FRONT (A - B)	REAR (D - C)
18 in. Wheel	98 mm (3.858 in.)	93 mm (3.661 in.)
19 in. Wheel	98 mm (3.858 in.)	93 mm (3.661 in.)

Measuring points:

A

Ground clearance of front wheel center

B

Ground clearance of front center position of front No. 2 suspension lower arm assembly front bush installation

C

Ground clearance of pit center of the attachment rear suspension arm


D

Ground clearance of rear wheel center

NOTICE:

Before inspecting the wheel alignment, adjust the vehicle height to the specified value.

If the vehicle height is not as specified, adjust the height by pressing down on the vehicle several times to stabilize the suspension.



4. INSPECT TOE-IN


(a) Bounce the vehicle up and down at the corners to stabilize the suspension and inspect toe-in.

Toe-in (w/ Air Suspension):

Toe-in (total)	B - A: 0 +/-2 mm (0 +/-0.08 in.)
----------------	----------------------------------

Toe-in (w/o Air Suspension):

Toe-in (total)	B - A: 1 +/-2 mm (0.04 +/-0.08 in.)
----------------	-------------------------------------



If toe-in is not within the specified range, adjust it at the rack ends.

5. ADJUST TOE-IN

(a) Measure the thread lengths of the right and left rack ends.

Standard:

Difference in thread length of 1.5 mm (0.059 in.) or less

(b) Remove the rack boot set clips.

(c) Loosen the tie rod end lock nuts.

(d) Adjust the rack ends if the difference in thread length between the right and left rack ends is not within the specified range.

(1) Extend the shorter rack end if the measured toe-in deviates toward the outer-side.

(2) Shorten the longer rack end if the measured toe-in deviates toward the inner-side.

(e) Turn the right and left rack ends by an equal amount to adjust toe-in.

HINT:

Try to adjust toe-in to the center of the specified range.

(f) Make sure that the lengths of the right and left rack ends are the same.


(g) Tighten the tie rod end lock nuts.

Torque:

55.9 N·m {571 kgf·cm, 41ft·lbf}

NOTICE:

Temporarily tighten the lock nut while holding the hexagonal part of the steering rack end so that the lock nut and the steering rack end do not turn together. Hold the width across flat of the tie rod end and tighten the lock nut.




(h) Perform the VGRS system calibration [INFO](#) .

(i) Place the boots on the seats and install the clips.

HINT:

- Make sure that the boots are not twisted.
- Make sure that the clips' finger grips are positioned as shown in the illustration.




6. INSPECT WHEEL ANGLE

(a) Turn the steering wheel fully to the left and right and measure the turning angle.

Standard wheel turning angle:


-	INSIDE WHEEL	OUTSIDE WHEEL: REFERENCE
Coil suspension 18 in.	41°45' (41.75°)	35°17' (35.28°)
Coil suspension 19 in.	40°46' (40.77°)	34°40' (34.67°)
Air suspension 18 in.	41°37' (41.62°)	35°11' (35.18°)
Air suspension 19 in.	40°38' (40.63°)	34°34' (34.57°)



If the right and left inside wheel angles differ from the specified range, check the right and left rack end lengths.

7. INSPECT CAMBER, CASTER AND STEERING AXIS INCLINATION

(a) Put the front wheels on the center of the alignment tester.



(b) Remove the center ornament.

(c) Install the camber-caster-steering axis inclination gauge at the center of the axle hub or drive shaft.

(d) Inspect the camber, caster and steering axis inclination.

Standard camber inclination (unloaded):

ITEM	CAMBER INCLINATION	
Coil suspension (Standard body)	Camber Left - right error	-0°17' +/-45' (-0.28° +/-0.75°) 30' (0.50°) or less
Coil suspension (Long body)	Camber Left - right error	-0°17' +/-45' (-0.28° +/-0.75°) 30' (0.50°) or less
Air suspension	Camber Left - right error	-0°26' +/-45' (-0.43° +/-0.75°) 30' (0.50°) or less

Standard caster inclination (unloaded):

ITEM	CASTER INCLINATION	
Coil suspension (Standard body)	Caster Left - right error	6°37' +/-45' (6.62° +/-0.75°) 45' (0.75°) or less
Coil suspension (Long body)	Caster Left - right error	6°37' +/-45' (6.62° +/-0.75°) 45' (0.75°) or less
Air suspension	Caster Left - right error	7°1' +/-45' (7.02° +/-0.75°) 45' (0.75°) or less

Standard steering axis inclination (unloaded):

ITEM	STEERING AXIS INCLINATION	
Coil suspension (Standard body)	Steering axis Left - right error	9°7' +/-45' (9.12° +/-0.75°) 30' (0.50°) or less
Coil suspension (Long body)	Steering axis Left - right error	9°7' +/-45' (9.12° +/-0.75°) 30' (0.50°) or less
Air suspension	Steering axis Left - right error	9°18' +/-45' (9.3° +/-0.75°) 30' (0.50°) or less

NOTICE:

- Inspect while the vehicle is empty.
- The maximum tolerance of right and left difference for the camber is 30' or less.
- The maximum tolerance of right and left difference for the caster is 45' or less.

(e) Remove the camber-caster-steering axis inclination gauge and attachment.


(f) Install the center ornament.

If the caster and steering axis inclination are not within the specified values, after the camber has been correctly adjusted, recheck the suspension parts for damaged and/or worn out parts.


8. ADJUST CAMBER AND CASTER

(a) Lift up the vehicle so that there is no load on the tires.

(b) Place a mark (with spray, etc.) over the front right vehicle side attachment area of the crossmember, which is indicated in the illustration.



- (c) Place a mark (with spray, etc.) over the front left vehicle side attachment area of the crossmember.
- (d) Loosen areas as necessary so that the front suspension crossmember can move.
- (e) Move the front suspension crossmember and adjust the camber and caster.



Relative alignment change based on amount of suspension crossmember movement in each direction:

		ALIGNMENT CHANGE AMOUNT				RELATIVE AMOUNT OF MOVEMENT BETWEEN SUSPENSION CROSSMEMBER AND VEHICLE BODY			
1	Suspension Crossmember Turn	Caster		Camber		Suspension Crossmember Installation Front Side LH		Suspension Crossmember Installation Front Side RH	
		LH	RH	LH	RH	Front to Rear	Left to Right	Front to Rear	Left to Right
		- 10'	+ 3'	+ 3'	- 3'	+ 1 mm (+ 0.0394 in.)	-	-	-
1'	Suspension Crossmember Turn	Caster		Camber		Suspension Crossmember Installation Front Side LH		Suspension Crossmember Installation Front Side RH	
		LH	RH	LH	RH	Front to Rear	Left to Right	Front to Rear	Left to Right
		+ 3'	- 10'	- 3'	+ 3'	-	-	+ 1 mm (+ 0.0394 in.)	-
2	Suspension Crossmember Front to Rear Movement	Caster		Camber		Suspension Crossmember Installation Front Side LH		Suspension Crossmember Installation Front Side RH	
		LH	RH	LH	RH	Front to Rear	Left to Right	Front to Rear	Left to Right
		- 7.5'	- 7.5'	+/- 0'	+/- 0'	+ 1 mm (+ 0.0394 in.)	-	+ 1 mm (+ 0.0394 in.)	-
2'		Caster		Camber					

		ALIGNMENT CHANGE AMOUNT				RELATIVE AMOUNT OF MOVEMENT BETWEEN SUSPENSION CROSSMEMBER AND VEHICLE BODY			
						Suspension Crossmember Installation Front Side LH		Suspension Crossmember Installation Front Side RH	
		LH	RH	LH	RH	Front to Rear	Left to Right	Front to Rear	Left to Right
		+ 7.5'	+ 7.5'	+/- 0'	+/- 0'	- 1 mm (- 0.0394 in.)	-	- 1 mm (- 0.0394 in.)	-
3	Suspension Crossmember Left to Right Movement	Caster		Camber		Suspension Crossmember Installation Front Side LH		Suspension Crossmember Installation Front Side RH	
		LH	RH	LH	RH	Front to Rear	Left to Right	Front to Rear	Left to Right
		+ 1'	- 1'	+ 7'	- 7'	-	+ 1 mm (+ 0.0394 in.)	-	+ 1 mm (0.0394 in.) (+ 0.0394 in.)
3'		Caster		Camber		Suspension Crossmember Installation Front Side LH		Suspension Crossmember Installation Front Side RH	
		LH	RH	LH	RH	Front to Rear	Left to Right	Front to Rear	Left to Right
		- 1'	+ 1'	- 7'	+ 7'	-	- 1 mm (- 0.0394 in.)	-	- 1 mm (- 0.0394 in.)


(f) Tighten the areas loosened previously.

9. ADJUST CAMBER

- (a) If the front suspension crossmember's left to right camber value is not as specified even though the camber and caster adjustment was performed, replace the No. 1 arm attachment plate inner and No. 2 arm attachment plate inner. Then perform the camber adjustment again.

Standard:

		NO. 1 ARM ATTACHMENT PLATE INNER		NO. 2 ARM ATTACHMENT PLATE INNER		CAMBER ANGLE CHANGE	CASTER ANGLE CHANGE
		RH	LH	RH	LH	-	-
Arm Attachment Part No. and Distinguishing Color	Standard Part	48614-50010 (Yellow)	48617-50010 (Yellow)	48614-50020 (White)	48617-50020 (White)	0 (Standard)	0 (Standard)
	+ 2 mm Part	48614-50030 (Pink)	48617-50030 (Pink)	48614-50050 (Green)	48617-50050 (Green)	+ 16.4'	+ 2.5'



HINT:

For +2 mm parts, the upper arm installation hole is further toward the outside of the vehicle compared to standard parts.


10. INSPECT FRONT SUSPENSION

- (a) Inspect the front suspension member.
- (1) Measure the dimension between the center of the installation bolts of the front No. 2 suspension lower arm.

Standard length:

788 mm (31.0236 in.)

If the result is not within the specification, replace the front suspension member.




(b) Inspect the front No. 1 suspension lower arm.

- (1) Remove the front No. 1 suspension lower arm **INFO** .
- (2) Measure the dimension between the center of the front No. 1 suspension lower arm bush and the ball joint stud.

Standard length:
385.5 mm (15.177 in.)

HINT:

If the dimension of the front suspension lower arm changes 2 mm (0.0787 in.), the camber will change approximately 15' (0.25°).




(c) Inspect the front No. 2 suspension lower arm.

- (1) Remove the front No. 2 suspension lower arm **INFO** .
- (2) Measure the dimension between the center of the front suspension lower arm bush and position A.

Standard length:
315.6 mm (12.425 in.)

HINT:

If the dimension of the front suspension lower arm changes 2 mm (0.0787 in.), the camber will change approximately 15' (0.25°).




(d) Inspect the front No. 1 suspension upper arm.

- (1) Remove the front No. 1 suspension upper arm **INFO** .
- (2) Measure the dimension between the center of the front No. 1 suspension upper arm bush and the ball joint stud.

Standard length:
235.8 mm (9.283 in.)

HINT:

If the dimension of the front suspension upper arm changes 2 mm (0.0787 in.), the camber will change approximately 15' (0.25°).



(e) Inspect the front No. 2 suspension upper arm.

- (1) Remove the front No. 2 suspension upper arm **INFO** .
- (2) Measure the dimension between the center of the front No. 2 suspension upper arm bush and the ball joint stud.

Standard length:
224.5 mm (8.839 in.)

HINT:

If the dimension of the front suspension upper arm changes 2 mm (0.0787 in.), the camber will change approximately 15' (0.25°).

