



Service Hints

G2 (B) Generator

- (B) 4–Ground : 13.9–15.1 volts with the engine running at 2000 rpm and 25°C (77°F)
13.5–14.3 volts with the engine running at 5000 rpm and 115°C (239°F)
(B) 1–Ground : 0–4 volts with the ignition SW at ON position and the engine not running

○ : Parts Location

Code		See Page	Code		See Page	Code		See Page
B3	A	38	G1	A	36	J1	37	
C9	A	38	G2	B	36	J22	40	
C12	D	38	I18		39			

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
2	22	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	26	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
ID		
IE		
IG	27	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	48	Engine No.2 Wire and Engine Room Main Wire (Near the Engine Room R/B)
IP4	54	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)