





I GROUND POINT






I GROUND POINT







I GROUND POINT



* 3 : w/o Driving Position Memory
 * 4 : w/ Driving Position Memory
 * 5 : Kinetic Dynamic Suspension System



I GROUND POINT



 : Parts Location

Code		See Page	Code		See Page	Code		See Page
J2	A	37	J23	40		J33		43
J3	B	37	J25	40		J34	A	46
J10		40	J28	43		J35	B	46
J11		40	J29	43		J36	A	46
J13		40	J31	43		J37	B	46
J14		40	J32	43				

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
2	22	Engine Room R/B (Engine Compartment Left)
3	23	Engine Room R/B No.3 (Engine Compartment Left)
4	23	Engine Room R/B No.4 (Engine Compartment Left)
5	24	Passenger Side R/B (Right Kick Panel)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IA	26	Roof Wire and Driver Side J/B (Lower Finish Panel)
IH	27	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	50	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IF1	52	Roof Wire and Instrument Panel Wire (Upper the Driver Side J/B)
IG1	52	Radio Installation Sub Wire and Instrument Panel Wire (Upper the Driver Side J/B)
IH1	52	Instrument Panel Wire and Instrument Panel Wire (Near the J/B No.1)
IJ1	52	Instrument Panel Wire and Instrument Panel No.2 Wire (Instrument Panel Brace LH)
IK1	52	Console Box Wire and Instrument Panel Wire (Under the Instrument Panel Brace LH)
IK2		
IM1	54	Instrument Panel Wire and Switch Wire (Front Side of the Console Box)
IN1	54	Floor No.3 Wire and Instrument Panel Wire (Under the Instrument Panel Brace RH)
IN2		
IO1	54	Engine Wire and Instrument Panel Wire (Right Side of the Blower Unit)
IO2		
IO3		
IQ1	56	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	58	Front Door LH Wire and Front Door LH Sub Wire (Inside of Front Door LH)
BC1	58	Rear Door LH Wire and Instrument Panel Wire (Center Pillar LH)
BD1	58	Rear Door RH Wire and Instrument Panel Wire (Center Pillar RH)
BG1	60	Frame No.3 Wire and Floor No.2 Wire (Left Side of Rear Floor Crossmember)
BH1	60	Back Door No.1 Wire and Floor Wire (Right Quarter Panel Inner)
BI1	60	Floor Wire and Rear A/C Sub Wire (Right Quarter Panel Inner)

I GROUND POINT



: Ground Points

Code	See Page	Ground Points Location
EA	48	Front Right Fender
EB	48	Front Left Fender
EC	48	Front Right Fender
ED	48	Rear Bank of Right Cylinder Head
EE		
EF		
EG	48	Rear Bank of Left Cylinder Head
IH	50	Left Kick Panel
II	50	Near the Left Side of Steering Column
IJ	50	Near the Right Side of Steering Column
IK	50	Instrument Panel Brace LH
IL	50	Right Kick Panel
BM	58	Under the Driver's Seat
BN	58	Under the Front Passenger's Seat
BO	58	Near the Left Side of No.5 Cross Member
BP	58	Left Quarter Panel Inner
BQ	58	Back Door Panel Center
BR	58	Right Quarter Panel Inner



: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	48	Engine Room Main Wire	B1	60	Roof Wire
E2			B2	60	Rear Door LH Wire
E5	48	Engine Wire	B3	60	Rear Door RH Wire
I2	52	Instrument Panel Wire	B4	60	Frame Wire
I3			B5	60	Back Door No.1 Wire
I6			B7	60	Floor Wire
I8			B9	60	Rear A/C Sub Wire
I11	52	Switch Wire			

