



# Power Source





# Power Source



## Service Hints

### HEAD Relay

5-3 : Closed with light control SW at HEAD position or dimmer SW at FLASH position  
Closed with the engine running and parking brake released (Parking brake SW off)

### I18 Ignition SW

2-3 : Closed with ignition key at ACC or ON position  
2-4 : Closed with ignition key at ON or ST position  
2-1 : Closed with ignition key at ST position  
7-6 : Closed with ignition key at ON or ST position  
7-8 : Closed with ignition key at ST position

### TAIL Relay

3-5 : Closed with light control SW at TAIL or HEAD position

## : Parts Location

Code	See Page	Code	See Page	Code	See Page
I18	<a href="#">39</a>				

## : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
2	<a href="#">22</a>	Engine Room R/B (Engine Compartment Left)
3	<a href="#">23</a>	Engine Room R/B No.3 (Engine Compartment Left)

## : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	<a href="#">26</a>	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
ID		