

- Malfunction in the exhaust solenoid valve:
The vehicle height is lowered to the normal height within 30 sec., and then the height control operation is suspended. The height control indicator lamp "N" comes on or blinks, and that of "HI" and "LO" do not illuminated by operating the height control switch "UP" and "DOWN".
- Abnormality of the tank solenoid valve:
Although the height control is still possible, the vehicle lowering speed may be slower.

WIRING DIAGRAM

