

3	CHECK HARNESS AND CONNECTOR(HEIGHT CONTROL SOLENOID VALVE OR EXHAUST SOLENOID VALVE – SUSPENSION CONTROL ECU)
----------	----------------------------------------------------------------------------------------------------------------------

- (a) Check for open and short circuit in the harness and the connectors between height control solenoid valve or the exhaust solenoid valve and the suspension control ECU (See page [01-36](#)).

NG	REPAIR OR REPLACE HARNESS OR CONNECTOR
-----------	-----------------------------------------------

OK

CHECK AND REPLACE SUSPENSION CONTROL ECU (See page 01-36)
