

Speech Command System

POI display on the map

	Automobile Club Triple A
	Auto Service & Maintenance Auto Service
	Gas Station Gas
	LEXUS Dealership LEXUS Dealer
	Parking Garage
	Parking Lot
	TOYOTA Dealership TOYOTA Dealer

	ATM
	Bank
	City Hall
	Civic Center Community Center
	Convention Center Exhibition Center
	Court House
	Higher Education University College

	Hospital
	Library
	Police Station
	School
	Amusement Park
	Casino
	Golf Course

Speech Command System

	Marina		Winery		Japanese Restaurant Japanese Food
	Museum		Restaurant I'm Hungry		Mexican Restaurant Mexican Food
	Park & Recreation Parks & Recreation		American Restaurant American Food		Seafood Restaurant Seafood
	Performing Arts		Chinese Restaurant Chinese Food		Other Restaurant Other Food
	Ski Resort Skiing		Continental Restaurant Continental Food		Grocery Store
	Sports Complex Stadium		French Restaurant French Food		Shopping Mall Shopping
	Tourist Attraction		Italian Restaurant Italian Food		Airport

Speech Command System

	Bus Station
	Commuter Rail Station
	Ferry Terminal
	Historical Monument
	Hotel
	Park & Ride
	Rental Car Agency

	Rest Area Rest Stop
	Tourist Information
	Train Station
	Business Facility
	City Center
Delete	POI Off

Speech Command System

Audio mode change

Command	Action
Radio	Changes to Radio mode.
AM	Changes to AM mode.
FM	Changes to FM mode.
FM 1	Changes to FM 1 mode.
FM 2	Changes to FM 2 mode.
CD Changer	Changes to CD Changer mode.
CD Changer 1*	Changes to CD Changer 1 mode.
CD Changer 2*	Changes to CD Changer 2 mode.
Cassette Tape	Changes to Tape Changer mode.
Audio On	Turns audio on.
Audio Off	Turns audio off.

* The command can be used only when you connect the other CD changer.

Radio operation

Command	Action
Seek Up	Seeks Up.
Seek Down	Seeks Down.

Tape operation

Command	Action
Fast Forward	Fast forwards the tape.
Rewind	Rewinds the tape.
Reverse Program	Reverses the tape.
Next Track	Plays Next track.
Previous Track	Plays Previous track.
Skip Backward	Plays Skip backward.

Speech Command System

Changer operation

Command	Action
Track Up	Plays next track.
Track Down	Plays current track.
Previous Track	Plays previous track.
Disc Up	Changes to next disc.
Next Disc	
Disc Down	Changes to previous disc.
Previous Disc	

Help operation

Command	Action
Help	Shows help command list.
Map	Gives the available command.
Destination	Gives the available command.
Guidance	Gives the available command.
Radio	Gives the available command.
Tape	Gives the available command.
Disc	Gives the available command.
Map Help	Gives the available command.
Destination Help	Gives the available command.
Guidance Help	Gives the available command.
Radio Help	Gives the available command.
Tape Help	Gives the available command.
Disc Help	Gives the available command.