

90 degree adjustable O2 extenders



Install restrictor with the largest hole to start. This restrictor works for most applications. If a P0420 (bank1) or P0430 (bank2) code is seen, use the next size smaller hole restrictor. If a slow response or low voltage code is seen, remove the restrictor and run with no restrictor in the extender.



Install on the rear O2 sensors in the midpipe, do not install on the front O2 sensors.