

**1994 Lexus ES 300**

HVAC SYSTEM 1994 Auto. A/C-Heater Systems

1. While pressing and holding AUTO and F/R (Fresh/Recirc) switches simultaneously, turn ignition on. Indicators will flash and tone will sound as a check. Press OFF button to cancel indicator check. After indicator check is complete, system will enter self-diagnostic mode. Stored trouble codes will appear in sequence on temperature display panel. See **AUTOMATIC A/C-HEATER SYSTEM TROUBLE CODES** table.
2. Press fan (down) button to display codes one at a time. If tone sounds when code is displayed, problem causing code currently exists. If tone does not sound when code is displayed, associated problem is past history and does not currently exist. Press OFF button to exit self-diagnostics.