
1 of 1

| Last Modified: 7-13-2007   |                     | 1.6 A                   |
|--|---------------------|-------------------------|
| Service Category: Vehicle Exterior   | Section: Door/Hatch |                         |
| Model Year: 2008   | Model: ES350        | Doc ID: RM0000010IU017X |
| Title: ENGINE HOOD / DOOR: LUGGAGE COMPARTMENT DOOR OPENER OUTER SWITCH: INSTALLATION (2008 ES350) |                     |                         |

## **INSTALLATION**

## 1. INSTALL LUGGAGE DOOR OPENING SWITCH ASSEMBLY



(a) Install the luggage door opening switch assembly with the 2 bolts.

- (b) Connect the connector.
- 2. INSTALL LUGGAGE COMPARTMENT DOOR COVER
- 3. INSTALL LUGGAGE COMPARTMENT DOOR INSIDE HANDLE
- 4. INSTALL LUGGAGE LOCK CONTROL CABLE PLATE
- 5. INSTALL LUGGAGE COMPARTMENT DOOR ASSIST GRIP

.

TOYOTA