


RADIO AND PLAYER (RHD)



* 1 : W/ LEXUS NAVIGATION SYSTEM
* 2 : W/O LEXUS NAVIGATION SYSTEM
* 3 : W/ CD AUTOMATIC CHANGER

