


Invisihitch Operating Instructions

Inserting the Ball Mount (or the bike-rack connector)

1) The lock should be in the unlocked position.



2) Turn the handle to the spring-loaded position.




3) Open dust cover and insert ball mount about an inch.



4) Align ball mount and then lift with force to snap it into place.




EXTREMELY IMPORTANT:
5) Push in the lock to secure the ball mount.




Removing the Ball Mount (or the bike-rack connector)

1) Insert key and unlock the receiver.



2) Turn handle clockwise while supporting the ball mount.



3) The ball mount will drop out when the handle is fully turned.



Common Mistakes:

1) Inserting the ball mount when the spring loaded mechanism is not in the loaded position.
The handle must be in the spring-loaded position to accept the ball mount.

2) Attempting to release the ball mount while the lock is engaged. Use the key to unlock the receiver; then turn the handle.