



Use the (-) Screw driver unscrew it

Unopen this 2 clips  
at the middle of  
these clips, by  
pushing it down

11/03/2010