






































K CONNECTOR LIST






K CONNECTOR LIST





K CONNECTOR LIST

E 1
Gray




E 2
Dark Gray




E 3
Black




E 4
Gray




E 5




E 6




E 7




E 8




E 9



F 1
Gray



F 2
Gray



F 3
Gray




F 4
Gray




F 5
Black



F 6
Dark Gray



F 7
Black



F 9



F 10




F 11
Black




F 12
Black




F 13




F 14






K CONNECTOR LIST


I11
Gray




I12
Gray




I13
Gray




I14
Gray




I15
Gray




I16
Gray




I17
Black



I18



I19
Black




I20




I21




I22




I23




I24




J 1




J 2
Blue




J 3
Blue




J 4
Dark Gray




J 5
Dark Gray




J 6
Dark Gray



J 7




J 8




J 9
Black




J10
Blue




J11




J12
Blue




J13




J14




J15
Blue




J16




J17
Black




J18
Black




J19
Black




J20
Black




J21
Blue




J22




J23




J24




J25




J26




J28




J29




J30



J31




J32




K CONNECTOR LIST


J33




J34




J35




J36




J37




J38




J39




J40




J41



J42




J43




J44




K 1
Black



K 2
Gray



K 3




L 1




L 2




L 3
Black




L 4
Black




M 1
Black




M 3
Black




M 4
Black




M 5




M 6




M10




M11




M12



M13



M14



N 1
Gray




N 2
Gray



N 3
Gray




N 4



N 5




N 6
Black



O 1
Gray




O 2




O 3
Black




O 4
Gray




O 5
Black




O 6
Gray




O 7
Gray




O 8
Black




P 1
Gray



P 2
Gray



P 3
Dark Gray



P 4
Black




P 5



P 6
Black




P 7




K CONNECTOR LIST


P 8




P 9




P10
Black




P11
Black




P12
Black




P13
Black




P14
Yellow




P15
Yellow




P16




P18
Black




P19




P20




P21
Black




P22
Black




P23
Black




P24
Black




P25
Black




P26




P27




P28




P29




P30
Black




R 1




R 2




R 3




R 4




R 5




R 6




R 7




R 8




R 9




R10




R11




R12




R13
Black



R14
Gray




R15
Gray



R17
Black




R18
Black




R19
Black



R20



R21




R22




R23




R24
Black




R25



R26




R27




R28
Black




R29



R30
Black




S 1




S 2
Black




S 3
Black




S 4




S 5




S 6



S 7
Blue



S12



S13




K CONNECTOR LIST


S14




S15




S16




S17
Blue




S18




S19




S20




S21
Yellow




S22
Yellow



S23
Yellow



S24
Yellow




S25




S26




S27



S28



S29



S30




S31
Yellow




S32
Yellow




S33
Black




S34
Black




S35
Black




S36



S37
Black




S38
Black




T 1
Black




T 2
Black




T 3
Black




T 4
Black




T 5




T 6




T 7




T 8



T 9



T10



T11
Black




T12
Black




K CONNECTOR LIST


T13




T14
Black




T15




T16
Blue




T17




T18
Black




T19




T20




T21




V 1
Black




V 2
Black




V 3
Black



V 4




V 5




V 7




V 9
Black



V10
Brown



V11
Brown



V12
Dark Gray



V13
Dark Gray



W 1
Black




W 2
Dark Gray




W 3
Gray




W 4




W 5
Blue



W 6



Y 1
Black



L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	A43	Air Injection Control Driver	90980-12068
A 2	A/C Condenser Fan Motor	90980-11237	A44	Air Injection Control Driver	90980-11858
A 3	A/C Lock Sensor	90980-11016	A45	Air Pressure Sensor	90980-10845
	A/C Magnetic Clutch		A46	Air Pump	90980-11032
A 7	ABS Speed Sensor Front LH	90980-11003	A47	Air Switching Valve	90980-11149
A 8	ABS Speed Sensor Front RH		B 1	Brake Fluid Level Warning SW	90980-11156
A 9	Absorber Control Actuator Front LH	90980-11929	B 2	Blower Motor Linear Controller	90980-11676
A10	Absorber Control Actuator Front RH		B 3	Body ECU	90980-12151
A11	Airbag Sensor Front LH	90980-11856	B 4	Body ECU	90980-12149
A12	Airbag Sensor Front RH		B 5	Body ECU	90980-12150
A13	A/C Control Assembly (w/o LEXUS Navigation System)	90980-12150	B 6	Back Door Courtesy SW	90980-10871
	A/C ECU (w/ LEXUS Navigation System)		B 7	Back Door Key Lock and Unlock SW	90980-12226
A14	A/C Control Assembly (w/o LEXUS Navigation System)	Back Door Lock Motor			
	A/C ECU (w/ LEXUS Navigation System)	Back Door Unlock Detection SW			
A15	A/C Control Assembly (w/o LEXUS Navigation System)	90980-12151	B 8	Back Door Speaker LH	90980-10860
	A/C ECU (w/ LEXUS Navigation System)		B 9	Back Door Speaker RH	
A16	A/C Room Temp. Sensor	90980-11918	B10	Back-Up Light LH	90980-11019
A17	A/C Solar Sensor	90980-12056	B11	Back-Up Light RH	
	Automatic Light Control Sensor		B12	Buckle SW LH	90980-10942
A18	A/C Thermistor	90980-11918		Seat Position Sensor	
A19	A/T Shift Indicator	90980-11911	B14	Buckle SW LH	90980-12366
A20	Accel Position Sensor	90980-11858	B15	Buckle SW RH	
A21	Acceleration Control Sensor Front	90980-10845	B16	Buckle SW RH	90980-11019
A22	Accessory Meter	90980-11911	C 1	Camshaft Position Sensor	90980-11016
A23	Air Inlet Control Servo Motor	90980-11909	C 2	Crankshaft Position Sensor	90980-11162
A24	Air Mix Control Servo Motor LH		C 3	CD Automatic Changer	90980-12262
A25	Air Mix Control Servo Motor RH		C 4	Center Diff. Lock Control SW	90980-11013
A26	Air Vent Mode Control Servo Motor		C 5	Center Diff. Lock ECU	90980-10801
A27	Airbag Sensor Assembly	82824-50160	C 6	Center Speaker	90980-10860
A28	Airbag Sensor Assembly	90980-11872	C 7	Cigarette Lighter	90980-10760
A29	Airbag Sensor Assembly	82824-50150	C 8	Cigarette Lighter Illumination	90980-11148
A30	Airbag Squib (Front Passenger Airbag Assembly)	90980-12160	C 9	Combination Meter	82824-35030
	A31		Airbag Squib (Steering Wheel Pad)	C10	Combination Meter
A32	Antenna Amplifier	90980-11146	C11	Combination Meter	82824-35030
A33	Ashtray Illumination	90980-10825	C12	Combination Meter	82824-35040
A34	ABS Speed Sensor Rear	90980-10942	C13	Combination SW	90980-12183
A35	Absorber Control Actuator Rear LH	90980-11930	C14	Combination SW	90980-11672
A36	Absorber Control Actuator Rear RH		C15	Combination SW	90980-11594
A37	Acceleration Control Sensor Rear	90980-10845	C16	Console Box Illumination	90980-10825
A38	Acceleration Sensor		C17	Curtain Shield Airbag Squib LH	90980-12219
A39	Accumulator Pressure Sensor No.1	90980-11451	C18	Curtain Shield Airbag Squib RH	
A40	Accumulator Pressure Sensor No.2		C19	Camshaft Timing Oil Control Valve LH	90980-11162
A41	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	90980-10869	C20	Camshaft Timing Oil Control Valve RH	
A42	Air Fuel Ratio Sensor (Bank 2 Sensor 1)		D 1	Detection SW (Transfer L4 Position)	90980-11156
			D 2	Detection SW (Transfer Neutral Position)	90980-10923
			D 3	Data Link Connector3	90980-11978

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
D 4	Diode (Back-Up Light)	90980-11071	F 6	Fuel Pump Resistor	90980-11156
D 5	Downhill Assist Control SW	90980-11013	F 7	Front Blower Motor	90980-10385
D 6	DVD Player	90980-12259	F 9	Front Door Speaker LH	90980-10935
D 7	Door Control Receiver	90980-11909	F10	Front Door Speaker RH	
D 8	Door Courtesy Light Front LH	90980-11148	F11	Front Door Squawker LH	90980-10860
D 9	Door Courtesy Light Front RH				
D10	Door Courtesy Light Rear LH				
D11	Door Courtesy Light Rear RH				
D12	Door Courtesy SW Front LH	90980-10871	F12	Front Door Squawker RH	90980-11013
D13	Door Courtesy SW Front RH				
D14	Door Courtesy SW Rear LH				
D15	Door Courtesy SW Rear RH				
D16	Door Key Lock and Unlock SW Front LH	90980-12226	F15	Fuel Pump	90980-11077
	Door Lock Motor Front LH		Fuel Sender		
	Door Unlock Detection SW Front LH		G 1	Generator	90980-09365
D17	Door Key Lock and Unlock SW Front RH		G 2	Generator	90980-11964
	Door Lock Motor Front RH		G 3	Gateway ECU	90980-11911
	Door Unlock Detection SW Front RH		G 4	Glove Box Light	90980-11148
D18	Door Lock Control SW LH	90980-12166	G 5	Glove Box Light SW	90980-11098
	Power Window Master SW		H 1	Headlight High LH	90980-11095
	Door Lock Control SW RH		H 2	Headlight High RH	
D19	Door Lock Control SW RH	90980-11950	H 3	Headlight Low LH	82824-60460
D20	Door Lock Motor Rear LH	90980-12226	H 4	Headlight Low RH	
	Door Unlock Detection SW Rear LH		H 6	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028
D21	Door Lock Motor Rear RH		H 8	Heated Oxygen Sensor (Bank 2 Sensor 2)	
	Door Unlock Detection SW Rear RH		H 9	Horn (High)	90980-10619
D22	Driving Position Memory SW	90980-11950	H10	Horn (Low)	
D23	Diode (Rear Interior Light)	90980-10962	H11	Hazard SW	90980-10789
E 1	Electronically Controlled Transmission Solenoid	90980-12293	H12	Headphone Terminal	90980-12156
E 2	Engine Coolant Temp. Sensor	90980-10735		Video Terminal	
E 3	Engine Hood Courtesy SW	90980-10942	H13	Heater Control SW	90980-11915
E 4	Electronically Controlled Transmission Pattern Select SW	90980-11013	H14	Height Control and Suspension SW	90980-11923
	Engine Control Module	90980-12527	H15	Height Control Compressor	90980-10990
E 6	Engine Control Module	90980-12528	H16	Height Control Exhaust Valve	90980-11859
E 7	Engine Control Module	90980-12526	H17	Height Control Sensor Rear LH	90980-11016
E 8	Engine Control Module	90980-12146	H18	Height Control Sensor Rear RH	
E 9	Engine Control Module	90980-12142	H19	High Mounted Stop Light	90980-11003
F 1	Front Fog Light LH	90980-11156	I 1	Ignition Coil and Igniter No.1	90980-11885
F 2	Front Fog Light RH				
F 3	Front Parking Light LH	90980-10942	I 2	Ignition Coil and Igniter No.2	
	Front Side Marker Light LH		I 3	Ignition Coil and Igniter No.3	
	Front Turn Signal Light LH		I 4	Ignition Coil and Igniter No.4	
F 4	Front Parking Light RH		I 5	Ignition Coil and Igniter No.5	
	Front Side Marker Light RH		I 6	Ignition Coil and Igniter No.6	
	Front Turn Signal Light RH		I 7	Ignition Coil and Igniter No.7	
F 5	Front Wiper Motor	90980-11599	I 8	Ignition Coil and Igniter No.8	
			I 9	Injector No.1	90980-11875
		I10	Injector No.2		
			I11	Injector No.3	
			I12	Injector No.4	
			I13	Injector No.5	

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
I14	Injector No.6	90980-11875	J34	Junction Connector	90980-12374
I15	Injector No.7		J35	Junction Connector	
I16	Injector No.8		J36	Junction Connector	
I17	Ignition Key Cylinder Light	90980-12092	J37	Junction Connector	
	Transponder Key Amplifier		J38	Junction Connector	
I18	Ignition SW	90980-11615	J39	Junction Connector	90980-12355
I19	Inner Mirror	90980-11794	J40	Junction Connector	
I20	Inside Handle Illumination Front LH	90980-12063	J41	Junction Connector	
I21	Inside Handle Illumination Front RH		J42	Junction Connector	
I22	Inside Handle Illumination Rear LH		J43	Junction Connector	
I23	Inside Handle Illumination Rear RH		J44	Junction Connector	90980-10871
I24	Interior Light	90980-12321	K 1	Knock Sensor (Bank 1)	90980-11875
J 1	Junction Connector	90980-11915	K 2	Knock Sensor (Bank 2)	
J 2	Junction Connector	90980-11661	K 3	Key Interlock Solenoid	90980-10795
J 3	Junction Connector			Unlock Warning SW	
J 4	Junction Connector	90980-10891	L 1	License Plate Light LH	90980-11148
J 5	Junction Connector		L 2	License Plate Light RH	
J 6	Junction Connector		L 3	Low Pressure Tank Valve	90980-11156
J 7	Junction Connector	90980-11661	L 4	Leak Detection Pump Assembly	90980-12380
J 8	Junction Connector		M 1	Mass Air Flow Meter	90980-12292
J 9	Junction Connector	90980-10803	M 3	Main SW	90980-10964
J10	Junction Connector	90980-11542	M 4	Mirror Heater SW	90980-10789
J11	Junction Connector	90980-10976	M 5	Multi-Display	90980-12203
J12	Junction Connector	90980-11542	M 6	Multi-Display	90980-12410
J13	Junction Connector	90980-11915	M10	Mirror Heater LH	90980-11573
J14	Junction Connector	90980-10976		Remote Control Mirror LH	
J15	Junction Connector	90980-11542	M11	Mirror Heater RH	
J16	Junction Connector	90980-11915		Remote Control Mirror RH	
J17	Junction Connector		M12	Moon Roof Control ECU and Motor	90980-10997
J18	Junction Connector		M13	Coin Box Illumination	90980-11923
J19	Junction Connector			Moon Roof Control SW	
J20	Junction Connector	Personal Light			
J21	Junction Connector	90980-11542	M14	Multi-Display	90980-12012
J22	Junction Connector	90980-11915	N 1	Noise Filter No.1	90980-10843
J23	Junction Connector	90980-10976	N 2	Noise Filter No.2	
J24	Junction Connector	90980-11915	N 3	Noise Filter (Condenser Fan)	
J25	Junction Connector	90980-11542	N 4	Navigation ECU	90980-11973
J26	Junction Connector	90980-11915	N 5	Navigation ECU	90980-11923
J28	Junction Connector	90980-11542	N 6	Navigation ECU	90980-12221
J29	Junction Connector		O 1	Oil Pressure SW	90980-11363
J30	Junction Connector	90980-11238	O 2	Overhead J/B	90980-12155
J31	Junction Connector		O 3	Occupant Classification ECU	90980-12356
J32	Junction Connector	90980-11686	O 4	Occupant Classification ECU	90980-12357
J33	Junction Connector	90980-11542	O 5	Occupant Detection Sensor Front LH	90980-12353

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
O 6	Occupant Detection Sensor Front RH	90980-12354	R 7	Rear Seat Entertainment ECU	90980-12200
O 7	Occupant Detection Sensor Rear LH		R 8	Rear Seat Entertainment ECU	90980-12183
O 8	Occupant Detection Sensor Rear RH	90980-12353	R 9	Rear Seat Entertainment ECU	90980-11923
P 1	Park/Neutral Position SW	90980-12362	R10	Remote Control Mirror ECU	90980-11877
P 2	Pressure SW	90980-11149	R11	Remote Control Mirror SW	90980-11657
P 3	Pressure SW	90980-10943	R12	Rheostat	90980-11989
P 4	Parking Brake SW	90980-10871	R13	Rain Sensor	90980-11987
P 5	Power Outlet (Front)	90980-10760	R14	Rear Combination Light LH	90980-10797
P 6	Power Outlet (115V)	90980-10601	R15	Rear Combination Light RH	
P 7	Power Window Control SW Front RH	90980-11947	R17	Rear Cooler Blower Motor	90980-10214
P 8	Power Window Control SW Rear LH		R18	Rear Cooler Magnetic Valve	90980-10860
P 9	Power Window Control SW Rear RH		R19	Rear Cooler Power Transistor	90980-10171
P10	Power Window Motor Front LH	90980-10797	R20	Rear Cooler Relay	90980-10713
P11	Power Window Motor Front RH		R21	Rear Cooler Thermistor	90980-10825
P12	Power Window Motor Rear LH		R22	Rear Door Speaker LH	90980-10935
P13	Power Window Motor Rear RH		R23	Rear Door Speaker RH	
P14	Pretensioner LH	90980-12253	R24	Rear Height Control Valve	90980-11143
P15	Pretensioner RH		R25	Rear Interior Light	90980-12321
P16	Power Seat Control SW (Driver's Seat Lumbar Support Control)	90980-10789	R26	Rear Seat Audio Controller	90980-12267
P18	Power Seat Control SW (Front Passenger's Seat)	90980-10997	R27	Rear Seat Entertainment Display	90980-12156
P19	Power Seat ECU and SW	90980-10801	R28	Rear Window Defogger	90980-10870
P20	Power Seat ECU and SW	90980-12221	R29	Rear Wiper Motor	90980-10795
P21	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825	R30	Roll Sensing Curtain Shield Airbag Cut Off SW	90980-11013
P22	Power Seat Motor (Driver's Seat Lifter Control)		S 1	Starter	90980-09585
P23	Power Seat Motor (Driver's Seat Lumbar Support Control)		S 2	Starter	90980-11400
P24	Power Seat Motor (Driver's Seat Reclining Control)		S 3	Seat Heater SW Front LH	90980-10964
P25	Power Seat Motor (Driver's Seat Slide Control)		S 4	Seat Heater SW Front RH	90980-10933
P26	Power Seat Motor (Front Passenger's Seat Reclining Control)		S 5	Shift Lock Control ECU	90980-12183
P27	Power Seat Motor (Front Passenger's Seat Slide Control)			Transmission Control SW	
P28	Passenger Airbag ON-OFF Indicator	90980-10797	S 6	Short Pin	90980-10800
	Passenger Seat Belt Warning Light		S 7	Short Pin	90980-10801
P29	Power Seat Control SW (Front Passenger's Seat Lumbar Support Control)	90980-10789	S12	Steering Sensor	90980-12155
P30	Power Seat Motor (Front Passenger's Seat Lumbar Support Control)	90980-10825	S13	Step Light LH	90980-12063
R 1	Radio and Player	90980-12038	S14	Step Light RH	
R 2	Radio and Player	90980-12259	S15	Stereo Component Amplifier	90980-11877
R 3	Radio and Player	90980-12183	S16	Stereo Component Amplifier	90980-10848
R 4	Rear Cooler SW	90980-11909	S17	Stop Light SW	90980-11118
R 5	Rear Seat Entertainment ECU	90980-12153	S18	Suspension Control ECU	90980-12150
R 6	Rear Seat Entertainment ECU	90980-12259	S19	Suspension Control ECU	90980-12149
			S20	Suspension Control ECU	90980-12151
			S21	Side Airbag Sensor Front LH	90980-12225
			S22	Side Airbag Sensor Front RH	
			S23	Side Airbag Sensor Rear LH	
			S24	Side Airbag Sensor Rear RH	

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
S25	Side Step Light LH	90980-11075	V12	VVT Sensor LH	90980-10947
S26	Side Step Light RH		V13	VVT Sensor RH	
S27	Sub Body ECU	90980-11877	W 1	Washer Level Sensor	90980-11068
S28	Sub Body ECU	90980-12113	W 2	Washer Motor	90980-11028
S29	Seat Heater (Driver's Seat)	90980-10797	W 3	Wireless Door Lock Buzzer	90980-11142
S30	Seat Heater (Front Passenger's Seat)		W 4	Wiper Relay	90980-12183
S31	Side Airbag Squib LH	90980-11864	W 5	Wiper Relay	90980-10801
S32	Side Airbag Squib RH		W 6	Woofer Speaker	90980-10795
S33	Stabilizer Control Valve	90980-11150	Y 1	Yaw Rate Sensor	90980-11904
S34	Stabilizer Control ECU	82824-48140			
S35	Stabilizer Control ECU	82824-48130			
S36	Stabilizer Control ECU	90980-12151			
S37	Skid Control ECU with Actuator	90980-12297			
S38	Skid Control ECU with Actuator	90980-12294			
T 1	Theft Deterrent Horn	90980-10619			
T 2	Throttle Control Motor	90980-11858			
	Throttle Position Sensor				
T 3	Transfer Actuator	90980-11664			
T 4	Turbine Speed Sensor	90980-11156			
T 5	Theft Deterrent ECU	90980-12169			
T 6	Tilt and Telescopic ECU	90980-11973			
T 7	Tilt Motor	90980-10797			
T 8	Towing Brake Controller	90980-11603			
T 9	Transponder Key Computer	90980-11911			
T10	Turn Signal Flasher	90980-10803			
T11	Tension Reducer Solenoid LH	90980-12063			
T12	Tension Reducer Solenoid RH				
T13	Towing Converter Relay	90980-11535			
T14	Trailer Socket	82824-34030			
T15	Tire Pressure Monitor ECU	90980-12155			
T16	Tire Select SW	90980-10825			
T17	Television Camera	90980-12211			
T18	Television Camera ECU	90980-12150			
T19	Television Camera ECU	90980-12149			
T20	Television Camera ECU	90980-12151			
T21	Tire Pressure Receiver	90980-11909			
V 1	Vehicle Speed Sensor (Electronically Controlled Transmission)	90980-11156			
V 2	VSV (EVAP)				
V 3	VSC Warning Buzzer	90980-10906			
V 4	Vanity Light LH	90980-12322			
V 5	Vanity Light RH				
V 7	Voltage Inverter	90980-10799			
V 9	VSV (ACIS)	90980-11156			
V10	VSV (Air Switching Valve Bank 1)	90980-11149			
V11	VSV (Air Switching Valve Bank 2)				

Note: Not all of the above part numbers of the connector are established for the supply.

