

雷克萨斯系列多媒体接口盒安装使用说明

Installation Instruction for Lexus Series Multimedia Video Interface

For Car Model: 2005-2009 Lexus IS/LS/ES/RX

1.安装前注意事项-----1

用户手册

多媒体导航娱乐系统

一.电气安全(Electrical safety)

安装前注意事项 Attentions before installation

1.为避免车载电器和本产品遭到因短路等原因导致的损坏,请拆卸,加装汽车电子部件之前请先关闭汽车

Please turn off the power of keys before install automotive electronic components to avoid

any damage to car electronics due to various of reasons, such as short circuit

用户手册

适用车型为:

多媒体导航娱乐系统

2005-2009款雷克萨斯



Click the calibration icon to come into touch screen calibrate, as the following picture 依照画面提示点击中心光标位置,直到校正光标自动移至左上角位置,并依次分别校正左下角,右下角,右上 角光标位置。如校正未成功将自动进入重新校正界面,触摸屏校正完成,系统将记忆校正结果,断电不 Follow the prompts to click on the center position of the cursor, until the cursor moves to the top left corner automatically, and calibrate the cursor position one by one on lower-left corner, lower right corner and top right corner. If he calitration is failure, it will automatically enter into recalibration interface. If touch screen calibration finished, the system will remember the correction result. It won't be lost even when power off. It do not need to calibrate it again when 支持数字电视国家标准CMMB制式,支持数字电视的节目搜索,包括搜索、自动搜索和频率选择,实现 Support digital TV national standard CMMB system, support the digital television program search, including search, automatic search and frequency selection. Realize digital television 用户手册 Pause/Display MovePrevious 点击此按键可返回到主菜单 Movenext Click the menu to selectthe program Fastrewind Click the menu to selectthe program Fast Forward Click this button to selectnextchannel Click this button toreturn to channel

7.5 DVD播放 在使用DVD功能之前,需先设置碟盒品牌中对应的DVD碟盒。 下一页菜单 图标进入其界面,如下图: 击点 Thenext page menu DVD DisPlay You need to set the first disc box brand in the corresponding DVD box. 进入画中画 Come into the picture to come into its interface, as the following picture: in picture •