



PNC	Description	Qty	Usage	FDate	TDate	TRev	
19309	HARNESS SUB-ASSY, CAM POSITION SENSOR	01	2URGSE..USE20	2007-12			
82121	WIRE, ENGINE	01	USE20	2007-12	2010-08	0004	
82122	WIRE, ENGINE, NO.2	01	USE20	2007-12			
82123	WIRE, ENGINE, NO.3	01	USE20	2007-12			
82125N	WIRE, ENGINE, NO.5	01	USE20	2007-12			
82126	WIRE, ENGINE	01	USE20	2007-12			
82128A	WIRE, ENGINE, NO.8	01	USE20	2007-12			
82284	WIRE, EARTH	01	USE20	2007-12	2012-08	0038	
82286A	WIRE, EARTH, NO.2	01	USE20 : NO.1	2007-12			
82286A	WIRE, EARTH, NO.2	01	USE20 : NO.2	2007-12			
82817C	PROTECTOR, WIRING HARNESS, NO.4	01	USE20	2007-12			
82817D	PROTECTOR, WIRING HARNESS, NO.5	01	USE20	2007-12			
82817E	PROTECTOR, WIRING HARNESS, NO.6	01	USE20	2007-12			
82817F	PROTECTOR, WIRING HARNESS, NO.7	01	USE20	2007-12			
82817G	PROTECTOR, WIRING HARNESS, NO.8	01	USE20	2007-12			
82817J	PROTECTOR, WIRING HARNESS, NO.9	01	USE20	2007-12			
82817K	PROTECTOR, WIRING HARNESS, NO.10	01	USE20	2007-12			
82817L	PROTECTOR, WIRING HARNESS, NO.11	01	USE20	2007-12			
82817N	PROTECTOR, WIRING HARNESS, NO.13	01	USE20	2007-12			
82817P	PROTECTOR, WIRING HARNESS, NO.14	01	USE20	2007-12			
82817T	PROTECTOR, WIRING HARNESS, NO.15	01	USE20	2007-12			
82821M	COVER, CONNECTOR	01	USE20	2007-12	2014-08		

PNC	Description	Qty	Usage	FDate	TDate	TRev	
	BOLT, FLANGE						
	BOLT, FLANGE						
	BOLT, FLANGE W/WASHE						
	BOLT, FLANGE W/WASHE						
	BOLT, FLANGE W/WASHE						
	BOLT, W/WASHER						
	BOLT, W/WASHER						
	BOLT, W/WASHER						
	NUT						
	NUT, FLANGE						
	STUD, HEXALOBULAR						
	STUD, HEXALOBULAR						
	STUD, HEXALOBULAR						