

NAVIGATION MODE

DESTINATION

Go Home
Address
Delete final destination

MAP OPERATION

Show map
Zoom in
Zoom out

GUIDANCE HELP

Repeat guidance
Arrow guidance
Turn list guidance
Turn by turn guidance
Resume guidance
Stop guidance
Freeway guidance
Intersection guidance

SCREEN PREFERENCES

Single map
Dual map
Compass mode

VOLUME

Louder
Softer

NAVIGATION MODE

POI

Nearest "_____"
ATM
Airport
Amusement park
Bank
Barber shop
Car wash
Coffee house
Convenience store
Department store
Dry cleaning
Ferry terminal
Gas station
Golf course
Grocery store
Historical monuments
Home and garden
Library
Parks
Pharmacy
Post Office
Restaurant
Rest area or rest shop
Specialty food store
Sports complex
Theater
Tourist information
Video rental
Zoo
Hide Icons

TELEPHONE MODE

CALLING

Dial by number
Dial by name
Dial
Cancel

AUDIO MODE

MODE

Radio
AM
FM – FM1 or FM2
SAT
CD changer

FUNCTIONS

Audio on
Audio off
Next track
Previous track
Seek up
Seek down
Next disc
Previous disc

CLIMATE CONTROL MODE

TEMPERATURE

Automatic air conditioning
Automatic air conditioning on
Automatic air conditioning off
Raise temperature
Lower temperature
Warmer
Cooler
"_____" degrees (65-85)