

**BRAKE CONTROL > ELECTRONICALLY CONTROLLED BRAKE SYSTEM > C1391/69
Accumulator Leak Malfunction**

DESCRIPTION

The DTC is stored if a brake fluid, internal or other leak is detected due to improper sealing in the brake actuator or brake accumulator pump. Internal leakage is suspected if the pump motor operates frequently without braking.

DTC Code	Information Code	DTC Detection Condition	Trouble Area
C1391/69	591	When either of the following is detected: <ol style="list-style-type: none"> 1. Before braking and when the pump motor is running, the accumulator pressure sensor input does not rise. 2. Before braking and when the pump motor is not running, the falling rate of the accumulator pressure sensor input continues to be greater than the standard value. 	<ul style="list-style-type: none"> • Brake fluid leakage (Connection between accumulator and actuator, or actuator and wheel cylinder) • Brake actuator