




Radio Receiver Assembly





Connector "A"




Connector "B"




Connector "C"



CD Auto Changer




Connector "A"




Connector "B"




Power Amplifier




Connector "A"



Connector "B"




Woofer Amplifier



Motor Antenna Assembly



Power Switch



Front Speaker



Rear Speaker



Woofer Speaker

