2008 Lexus RX 350

2008 SUSPENSION Suspension Control - RX 350




Fig. 137: Identifying Height Control Compressor Replacement Components With Torque Specifications Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL

NOTE: Before disconnecting the air tube, press the height control OFF switch to stop the vehicle height control operation.