Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

| ltem                                       | Function   | Default setting  | Customized<br>setting                |
|--|--|--|--------------------------------------|
| Wireless<br>remote con-<br>trol<br>(→P. 4) | Unlocking operation  | Driver's door<br>unlocked in<br>one step, all<br>doors<br>unlocked in<br>two steps | All doors<br>unlocked in one<br>step |
|  | Automatic door lock<br>function to be activated if<br>door is not opened after<br>being unlocked | ON   | OFF                                  |
|  | Time elapsed before auto-<br>matic door lock function is<br>activated if door is not             | 60 seconds   | 30 seconds                           |
|  | opened after being<br>unlocked   |  | 120 seconds                          |
|  | Operation signal<br>(Emergency flashers)   | ON   | OFF                                  |
|  | Operation signal<br>(Buzzer)   | ON   | OFF                                  |

| ltem                                       | Function   | Default setting | Customized<br>setting |
|--|--|-----------------|-----------------------|
| Wireless<br>remote con-<br>trol<br>(→P. 4) | Buzzer sounds when<br>pushing LOCK with any<br>door not closed | ON              | OFF                   |
|  | Power back door opera-   | Push and hold   | Push twice*           |
|  | tion   |                 | One short push*       |
|  | Panic function   | ON              | OFF                   |
| Power back<br>door<br>(→P. 12)             | Switch operation   | Push and hold   | One short push        |
|  | Wireless remote control linked operation                       | ON              | OFF                   |
|  | Operation signal volume  | OFF             | High                  |
|  |  |                 | Low                   |
|  | Operation when door<br>locks                                   | Possible        | Impossible            |
|  | Assistance of opening with door opener                         | OFF             | ON                    |
|  | Sensitivity of jam protec-<br>tion function                    | Level 1         | Level 2 to 4          |

\*: It is possible to select them only when the power back door operation with the open/close switch is made impossible when the door is locked.

## 6-2. Customization

| ltem  | Function  | Default setting  | Customized<br>setting                 |
|---|---|--|---------------------------------------|
| Door lock<br>(→P. 7)                              | Unlocking using a key   | Driver's door<br>unlocked in<br>one step, all<br>doors<br>unlocked in<br>two steps | All doors<br>unlocked in one<br>step. |
|   | Speed-detecting auto-<br>matic door lock function                           | OFF  | ON                                    |
|   | Opening driver's door<br>unlocks all doors                                  | OFF  | ON                                    |
|   | Shifting gears to P unlocks all doors.                                      | ON   | OFF                                   |
|   | Shifting gears to position<br>other than P locks all<br>doors.              | ON   | OFF                                   |
| Power<br>windows<br>(→P. 40)                      | Linked door lock/unlock operation   | ON   | OFF                                   |
|   | Wireless remote control linked operation                                    | ON<br>(open only)  | OFF                                   |
| Moon roof<br>(→P. 43)                             | Linked door lock/unlock operation   | ON   | OFF                                   |
|   | Wireless remote control linked operation                                    | ON<br>(open only)  | OFF                                   |
| ٨   | Light sensor sensitivity  | Level 3  | Level1to 5                            |
| Automatic<br>light control<br>system<br>(→P. 116) | Time elapsed before<br>headlights automatically<br>turn off after doors are | 30 seconds   | 0 second                              |
|   |   |  | 60 seconds                            |
|   | closed  |  | 90 seconds                            |

| ltem  | Function  | Default setting | Customized<br>setting |
|---|---|-----------------|-----------------------|
| Windshield<br>wipers and<br>washer<br>(→P. 120) | Switching operation when<br>the vehicle is stationary | ON              | OFF                   |
| Illumination<br>(→P. 236)                       | Time elapsed before lights                            | 15 seconds      | 7.5 seconds           |
|   | turn off  | 10 30001103     | 30 seconds            |
|   | Operation when the doors are opened                   | ON              | OFF                   |
|   | Operation when the doors are unlocked                 | ON              | OFF                   |
|   | Operation after the engine is off                     | ON              | OFF                   |
| Steering<br>wheel<br>(→P. 34)                   | Automatic tilt-away steer-<br>ing column              | ON              | OFF                   |