

**LUXLINK CONTROLS FOR LEXUS SC430
(WITH QUARTER WINDOW MODULE)**

Control Sequence	Effect
<u>Dash button:</u> Press convertible <u>dash</u> button 2x	<u>Engine off:</u> - If windows & top closed, windows & top open. - If windows & top opened, windows & top close. <u>Engine on:</u> - If windows & top open, (i) windows & top close & (ii) car turns off afterwards.
<u>Key remote:</u> Unlock, Lock, Lock	Vehicle starts.
<u>Key remote:</u> Press & hold Unlock until long beep	Opens or closes top & windows.
<u>Key remote:</u> Press & hold Unlock until long beep, then Lock, Lock, Unlock	Vehicle starts & windows & top open. (**Note: If brake depressed before key is placed in ignition, engine shuts off.)
<u>Driver window switch:</u> Press driver window switch down (not all the way down) 3x	Rear quarter windows go up or down.
** Note: Driver door open before turning off key.	Luxlink is disabled.