



## Lexus U.S. &gt; SC430 &gt;2004 &gt;JPP &gt;1 - Tool/Engine/Fuel Grp &gt;16-03 - RADIATOR &amp; WATER OUTLET

PNC	Description	Part Number	Qty	Usage	FDate	TDate	TRev	
16206	PIPE SUB-ASSY, WATER BY-PASS	16206-50120	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16261	HOSE, WATER BY-PASS	16261-50090	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16261A	CLAMP OR CLIP, HOSE(FOR WATER BY-PASS HOSE)	96135-51300	02	3UZFE..UZZ40	2001-01	2005-01		
16268F	RING, O(FOR WATER BY-PASS PIPE)	96761-24019	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16279	PIPE, WATER BY-PASS, NO.3	16208-50030	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16295	HOSE, WATER BY-PASS, NO.7	16295-50070	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16295A	CLIP(FOR WATER BY-PASS HOSE NO.7)	96135-51300	02	3UZFE..UZZ40	2001-01	2005-01		
16321	INLET, WATER	16321-50020	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16323	HOUSING, WATER INLET	16032-50110	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16323C	RING, O(FOR WATER INLET HOUSING)	96761-35035	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16331A	THERMOSTAT	90916-03100	01	3UZFE..UZZ40 : *WAX 82-95	2001-01	2005-08	0010	
16346	GASKET, THERMOSTAT	16346-50010	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16355	JOINT, WATER BY-PASS, FRONT	16355-50070	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16355A	GASKET(FOR WATER BY-PASS JOINT FRONT)	16341-50020	02	3UZFE..UZZ40	2001-01	2005-08	0010	
16356	JOINT, WATER BY-PASS, REAR	16356-50090	01	3UZFE..UZZ40	2001-01	2005-08	0010	
16356A	GASKET(WATER BY-PASS JOINT, REAR)	16341-50020	02	3UZFE..UZZ40	2001-01	2005-08	0010	
	BOLT, FLANGE	91511-J0822						
	BOLT, STUD	92122-B0822						
	BOLT, STUD	92122-B0825						
	BOLT, WASHER BASED H	90105-08267						
	CLIP	90467-20011						
	NUT	90179-08153						
	PLUG, TAPER SCREW W/	90345-51011						
	RPL 9011908951	91621-J0814						