


# G ELECTRICAL WIRING ROUTING

## Position of Parts in Instrument Panel

[LHD]



- |     |  |     |                         |
|-----|--|-----|-------------------------|
| A10 | A/C Control Assembly                               | B 5 | Blower Motor            |
| A11 | A/C Control Assembly                               | B 6 | Blower Motor Controller |
| A12 | A/C Control Assembly                               | B 7 | Blower Motor Controller |
| A13 | A/C Room Temp. Sensor                              |     |                         |
| A14 | A/C Solar Sensor<br>Automatic Light Control Sensor |     |                         |
| A15 | A/C Thermistor                                     |     |                         |
| A16 | A/T Shift Lever Illumination                       |     |                         |
| A17 | Accel Position Sensor                              |     |                         |
| A18 | Air Foot Control Servo Motor                       |     |                         |
| A19 | Air Inlet Control Servo Motor                      |     |                         |
| A20 | Air Mix Control Servo Motor (Driver Side)          |     |                         |
| A21 | Air Mix Control Servo Motor (Passenger Side)       |     |                         |
| A22 | Air Vent Mode Control Servo Motor                  |     |                         |
| A23 | Airbag Sensor Assembly                             |     |                         |
| A24 | Airbag Sensor Assembly                             |     |                         |
| A25 | Airbag Sensor Assembly                             |     |                         |
| A26 | Airbag Squib (Front Passenger Airbag Assembly)     |     |                         |
| A27 | Airbag Squib (Steering Wheel Pad)                  |     |                         |
| A28 | Audio Door Control SW                              |     |                         |