


## Position of Parts in Seat



- |  |  |
|--|--|
| <p>B10 Buckle SW LH</p> <p>B11 Buckle SW RH and Occupant Detection Sensor</p> <p>J19 Junction Connector</p> <p>J20 Junction Connector</p> <p>J21 Junction Connector</p> <p>J22 Junction Connector</p> <p>L25 Lumbar Support Control Motor (Driver's Seat)</p> <p>L26 Lumbar Support Control Motor (Front Passenger's Seat)</p> <p>L27 Lumbar Support Control SW (Driver's Seat)</p> <p>L28 Lumbar Support Control SW (Front Passenger's Seat)</p> <p>P19 Power Seat Control SW (Driver's Seat)</p> <p>P20 Power Seat Control SW (Front Passenger's Seat)</p> <p>P21 Power Seat ECU (Driver's Seat)</p> <p>P22 Power Seat ECU (Driver's Seat)</p> <p>P23 Power Seat ECU (Front Passenger's Seat)</p> <p>P24 Power Seat ECU (Front Passenger's Seat)</p> <p>P25 Power Seat Motor (Driver's Seat Front Vertical Control)</p> <p>P26 Power Seat Motor (Driver's Seat Lifter Control)</p> <p>P27 Power Seat Motor (Driver's Seat Reclining Control)</p> <p>P28 Power Seat Motor (Driver's Seat Slide Control)</p> <p>P29 Power Seat Motor<br/>(Front Passenger's Seat Front Vertical Control)</p> | <p>P30 Power Seat Motor<br/>(Front Passenger's Seat Lifter Control)</p> <p>P31 Power Seat Motor<br/>(Front Passenger's Seat Reclining Control)</p> <p>P32 Power Seat Motor<br/>(Front Passenger's Seat Slide Control)</p> <p>P33 Power Seat Position Sensor<br/>(Driver's Seat Front Vertical Control)</p> <p>P34 Power Seat Position Sensor (Driver's Seat Lifter Control)</p> <p>P35 Power Seat Position Sensor<br/>(Driver's Seat Reclining Control)</p> <p>P36 Power Seat Position Sensor (Driver's Seat Slide Control)</p> <p>P37 Power Seat Position Sensor<br/>(Front Passenger's Seat Front Vertical Control)</p> <p>P38 Power Seat Position Sensor<br/>(Front Passenger's Seat Lifter Control)</p> <p>P39 Power Seat Position Sensor<br/>(Front Passenger's Seat Reclining Control)</p> <p>P40 Power Seat Position Sensor<br/>(Front Passenger's Seat Slide Control)</p> <p>S24 Seat Heater Controller (Driver's Seat)</p> <p>S25 Seat Heater Controller (Front Passenger's Seat)</p> <p>S26 Side Airbag Squib LH</p> <p>S27 Side Airbag Squib RH</p> |
|--|--|