2004-5 SC-430 NA	AVI Voice Commands
Command	Alternate Commands with same function
Current position	Current Location
Map	
Cancel	
Zoom In	
Zoom Out	
Right Map Zoom In	
Right Map Zoom Out	
North Up	Change to north up
Heading Up	Change to heading up
Map direction	Change to map direction
Right map north up	
Right map heading up	
Right map direction	
Dual map	Change to dual map
Single map	Change to single map
Mark this point	Mark
Restaurant	I'm hungry
Japanese restaurant	Japanese food
Chinese restaurant	Chinese food
French restaurant	French food
Italian restaurant	Italian food
Other restaurant	Other food
American restaurant	American food
Continental restaurant	Continental food
Mexican restaurant	Mexican food
Seafood restaurant	Seafood
Shopping	Shopping mall
Grocery store	
Gas station	Gas

Parking	Parking lot, Parking garage
Rental car agency	Rental Car
TOYOTA dealership	TOYOTA dealer
LEXUS dealership	LEXUS dealer
Auto club	Automobile club, Triple A
Service & maintenance	Auto service & maintenance, Auto service
Hotel	
Golf Course	Golf
Ski resort	Skiing
Amusement park	
Sports complex	Stadium
Casino	
Marina	
Tourist attraction	
Winery	
City hall	
Police Station	
Library	
Hospital	
Park	Park & Recreation
Government Offices	Civic Center, Community Center
Convention Center	Exhibition Center
Court house	
Train station	
Commuter rail station	
Airport	
Bus station	
Ferry terminal	
Rest area	Rest stop
Tourist Information	

Historical	
Monument	
Performing Arts	Theater
Museum	
Bank	
School	
ATM	
Higher Education	University, College
Business Facility	Other business facilities, Other Business
City Center	
Car Wash	
Other Automotive Stores	Other Automotive
Other Financial Services	Other Financial
Post office	
Botanical Garden	Zoological Garden, Zoo
Cinema	
Horse racing	
National and State Parks	National Parks
Speedway	
Video Rental	
Fast Food	
Thai	
Convenience Store	
Department Store	
Home and garden	
Pharmacy	
Specialty food store	Specialty food
Other retail stores	Other retail
Campground	
Beauty and barber shops	Barber shops
Coffee House	

Dry cleaning	
Health and fitness club	Fitness club
Ice cream parlor	
POI Off	
Home	Go Home
Previous starting point	Go to starting point, Previous start point, Go to start point
Previous destination	Go to previous destination
Quick access Number 1	Quick access 1, Go to quick access number 1, Go to quick access 1
Quick access Number 2	Quick access 2, Go to quick access number 2, Go to quick access 2
Quick access Number 3	Quick access 3, Go to quick access number 3, Go to quick access 3
Quick access Number 4	Quick access 4, Go to quick access number 4, Go to quick access 4
Quick access Number 5	Quick access 5, Go to quick access number 5, Go to quick access 5
Yes	
No	
Enter Destination	
Add to Destination	
Replace Destination	
Repeat Guidance	Repeat voice, Repeat
Louder	
Softer	
Arrow guidance	Arrow guide, Change to arrow guidance, Change to arrow guide
Turn list guidance	Turn list guide, Change to turn list guidance, Change to turn list guide

Entire Route map	Entire route, route overview
Next destination map	
First destination map	
Second destination map	
Third destination map	
Fourth destination map	
Fifth destination map	
Final destination map	
Delete next destination	Cancel next destination
Delete final destination	Cancel final destination
Delete all destinations	Cancel all destinations
Detour	Detour entire route
Suspend guidance	Stop guidance
Resume guidance	Start guidance
Quick 1	Quick
Quick 2	
Short	
Freeway Guidance	Freeway guide, Change to freeway guidance, Change to freeway guide
Intersection guidance	Intersection guide, Change to intersection guidance, Change to intersection guide
Compass mode	Change to compass mode
Lane guidance	Change to lane guidance, Guidance

Radio AM AM Radio FM FM Radio FM1 FM2 CD DVD CD Changer Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Disc up Next disc Disc down Previous disc Screen On Screen Off Help Command list Command help, Command list	AUDIO Commands		
FM FM Radio FM1 FM2 CD DVD CD Changer Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Radio		
FM1 FM2 CD DVD CD Changer Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Screen On Screen Off Help Commands Command help,	AM	AM Radio	
FM2 CD DVD CD Changer Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen On Screen Off Help Commands Command help,	FM	FM Radio	
CD DVD CD Changer Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	FM1		
CD Changer Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	FM2		
CD Changer Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	CD		
Cassette Tape Audio Audio on, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen Off Help Commands Help Command Naudio on, Audio off Audio on, Audio on, Audio off Next disc on, Audio off Previous off Next forward Next track Previous track Track down Previous track Disc up Next disc Commands	DVD		
Tape Audio Audio on, Audio off Seek up Seek down Type up Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen Off Help Commands Help Command help,	CD Changer		
Audio On, Audio off Seek up Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen On Screen Off Help Commands Command help,	Cassette		
Seek down Type up Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen On Screen Off Help Commands Command help,	Tape		
Seek down Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen On Screen Off Help Commands Command help,	Audio	Audio on, Audio off	
Type up Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen On Screen Off Help Commands Command help,	Seek up		
Type down Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Seek down		
Fast forward Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Type up		
Rewind Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Type down		
Reverse Program Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Fast forward		
Next track Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Rewind		
Previous track Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Reverse	Program	
Skip backward Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Next track		
Play Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Previous track		
Track up Next track Track down Previous track Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Skip backward		
Track down Disc up Next disc Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Play		
Disc up Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Track up	Next track	
Disc down Previous disc Screen Display Commands Screen On Screen Off Help Commands Command help,	Track down	Previous track	
Screen Display Commands Screen On Screen Off Help Commands Command help,	Disc up	Next disc	
Screen On Screen Off Help Commands Command help,	Disc down	Previous disc	
Screen On Screen Off Help Commands Command help,			
Help Commands Command help,	Screen Display Commands		
Help Commands Command help,			
Help Command help,			
Hein	_		
	Help	Command help, Command list	