

SC 430 Voice Commands	
<i>Command</i>	<i>Alternate Commands with same function</i>
Help Commands	
Help	Command list, Command help
Screen Display Commands	
Screen On	
Screen Off	
Current position	Current Location
Map	
Cancel	
Zoom In	
Zoom Out	
Right Map Zoom In	
Right Map Zoom Out	
North Up	Change to north up
Heading Up	Change to heading up
Map direction	Change to map direction
Right map north up	
Right map heading up	
Right map direction	
Dual map	Change to dual map
Single map	Change to single map
Mark this point	Mark
Restaurant	I'm hungry
Japanese restaurant	Japanese food
Chinese restaurant	Chinese food
Italian restaurant	Italian food
Mexican restaurant	Mexican food
Shopping	Shopping mall
Grocery store	
Gas station	Gas
Parking	Parking lot, Parking garage

LEXUS dealership	LEXUS dealer
Service & maintenance	Auto service & maintenance, Auto service
Hotel	
Hospital	
Rest area	Rest stop
Museum	
Car Wash	
Post office	
Cinema	
National and State Parks	National Parks
Speedway	
Pharmacy	
Coffee House	
Dry cleaning	
POI Off	
Home	Go Home
Previous starting point	Go to starting point, Previous start point, Go to start point
Previous destination	Go to previous destination
Quick access Number 1	Quick access 1, Go to quick access number 1, Go to quick access 1
Quick access Number 2	Quick access 2, Go to quick access number 2, Go to quick access 2
Quick access Number 3	Quick access 3, Go to quick access number 3, Go to quick access 3
Quick access Number 4	Quick access 4, Go to quick access number 4, Go to quick access 4
Quick access Number 5	Quick access 5, Go to quick access number 5, Go to quick access 5
Enter Destination	
Add to Destination	

Replace Destination	
Repeat Guidance	Repeat voice, Repeat
Louder	
Softer	
Arrow guidance	Arrow guide, Change to arrow guidance, Change to arrow guide
Turn list guidance	Turn list guide, Change to turn list guidance, Change to turn list guide
Entire Route map	Entire route, route overview
Next destination map	
First destination map	(through "Fifth Dest. Map")
Final destination map	
Delete next destination	Cancel next destination
Delete final destination	Cancel final destination
Delete all destinations	Cancel all destinations
Detour	Detour entire route
Suspend guidance	Stop guidance
Resume guidance	Start guidance
Quick 1	Quick
Quick 2	
Short	
Freeway Guidance	Freeway guide, Change to freeway guidance, Change to freeway guide
Intersection guidance	Intersection guide, Change to intersection guidance, Change to intersection guide
Compass mode	Change to compass mode
Lane guidance	Change to lane guidance, Guidance screen on freeway

AUDIO Commands	
<i>Command</i>	<i>Alternate Commands with same function</i>
Radio	
AM	AM Radio
FM	FM Radio
FM1	
FM2	
CD	
CD Changer	
Cassette	
Tape	
Audio	Audio on, Audio off
Seek up	
Seek down	
Type up	
Type down	
Fast forward	
Rewind	
Reverse	Program
Next track	
Previous track	
Skip backward	
Play	
Track up	Next track
Track down	Previous track
Disc up	Next disc
Disc down	Previous disc