Navigation system* P.53
Lexus Display Audio system* P.69

Air conditioning system P.78

Clock*

Tilt and telescopic steering control switch**

Seat ventilator switches* P.81

HUD (Head-up display) switches**

Seat heater switches* P.81



Emergency flasher switch*

Audio system P.64, 74

Tilt and telescopic steering lock release lever**

See P.9

Shift lever P.18

Seat heater switches* P.81

ASC (Active Sound Control) dial* P.49

*: If equipped
*: Refer to "OWNER'S MANUAL".

A



BSM (Blind Spot Monitor) main switch* P.47

Intuitive parking assist switch**

Power back door switch* P.99

Instrument panel light control switches*

Automatic High Beam switch* P.27

Odometer/trip meter and trip meter reset button*

PCS (Pre-Collision System) switch**

Heated steering wheel switch**

Rear seat operations switch**

All-wheel drive lock switch**