



Technical Service Information Bulletin

June 24, 2004

REPAIR MANUAL SUPPLEMENT: SMART KEY REGISTRATION

Models: '04 - '06 LS 430

REVISIONED EL003-04 ELECTRICAL

TSIB REVISION NOTICE:

- December 9, 2005: 2005 and 2006 model years have been added to Applicable Vehicles. Diagnostic Tester software version has been updated to 13.2a. Previous versions of this TSIB should be discarded.

Introduction The following procedure should be used to add an additional Smart Key (Immobilizer and Smart/Wireless functions) to the 2004 - 2006 model year LS 430.

Applicable Vehicles • 2004 - 2006 model year LS 430 vehicles.

Required SSTs

Table with 5 columns: ITEM NO., SPECIAL SERVICE TOOLS (SSTs), PART NUMBER, QTY, DRW**. Row 1: Lexus Diagnostic Tester Kit* (NOTE: All components from this kit/set are required... 12 Megabyte Diagnostic Tester Program Card...), LEX220036, 1, 8. Row 2: CAN Interface Module Kit* (NOTE: All components from this kit/set are required), 01002744, 1, 8.

* Essential SSTs.

** Refers to drawer number in SST Storage System.

NOTE:

Additional Diagnostic Tester Kits, CAN Interface Modules, Program Cards, or other SSTs may be ordered by calling SPX/OTC at 1-800-933-8335.

Warranty Information


Table with 6 columns: OP CODE, DESCRIPTION, TIME, OFF, T1, T2. Row 1: N/A, Not Applicable to Warranty, -, -, -, -.



Registration Procedure

- 1. Make sure that the key is NEW (has never been registered to another vehicle) and verify that it is a Master Key (has a trunk button). Sub-keys will NOT have a trunk button and have NO Smart function. 2. Place the vehicle in an area that is free from radio frequency interference... 3. Turn off or remove from the vehicle interior any wireless communication devices... 4. Insert a registered Smart Key into the ignition. 5. Turn the ignition to the ON position, but do not start the engine. 6. Connect Diagnostic Tester to DLC3. 7. If the Diagnostic Tester backlighting is ON, use the screen flow below to turn it "OFF" to prevent possible signal interference. If backlighting is already OFF, proceed to step 8.


A. Turn the Diagnostic Tester power ON and follow the screen flow below.




B. Turn the Diagnostic Tester power OFF and back ON.

Registration Procedure: Immobilizer Function

8. Register the Immobilizer function.
 - A. Follow the Diagnostic Tester screen flows below. This procedure works best if you use the instructions under the "DO THIS" column and use the screen prints to know WHEN to perform the instructions only.
 - B. Verify that a registered master key is in the key slot and the ignition is ON.



Registration Procedure: Immobilizer Function
(Continued)



Registration
Procedure:
Immobilizer
Function
(Continued)

(Continued from previous page)

**WHEN THIS
SCREEN APPEARS:**

I

Please remove the Master Key from the IG cylinder, insert it again, and turn the IG ON within 120 seconds. Then press [ENTER]

Remaining Time:
[116] Sec.

DO THIS:

- (Within 120 seconds)
- Turn the ignition OFF
 - Remove the registered key from the key cylinder
 - Reinsert the registered key
 - Turn the ignition to ON
 - Press "ENTER"

J

Please remove the Master Key from the IG cylinder within 20 seconds. Then press [ENTER]

Remaining Time:
[16] Sec.

- (Within 20 seconds)
- Turn the ignition OFF
 - Remove the Registered key from the key cylinder
 - Press "ENTER"

K

Please insert the New Key into the IG cylinder within 10 seconds. Then press [ENTER].

DO NOT TURN IG ON

Remaining Time:
[8] Sec.

- (Within 10 seconds)
- Insert the NEW KEY into the key cylinder
 - DO NOT turn the ignition ON
 - Press "ENTER"

L

****NOW REGISTERING****

Please wait.
[15] SECONDS

No action required

(Continued next page)

Registration
Procedure:
Immobilizer
Function
(Continued)

(Continued from previous page)

**WHEN THIS
SCREEN APPEARS:**

M

THE
IMMOBILISER CODE
WAS REGISTERED
CORRECTLY.

PRESS [ENTER]

DO THIS:

- Wait for this screen to appear.
- Press "ENTER"
- Remove the new key from the key slot
- Reinsert the ORIGINAL key into the key slot

N

Please insert a Master Key and turn the IG to ON.

If the ignition is already ON, please turn it OFF and back to ON.

PRESS [ENTER]

- Turn the ignition ON
- Press "ENTER"

O

<RESULT>
Code
registration was
successful.


Do you wish to
register another
Code?

PRESS [YES] or [NO]


Immobilizer Registration
is complete

Registration Procedure:
Smart Key/
Wireless
Function

9. Register the Smart Key / Wireless function.
 - A. From the Immobilizer ID Utility menu (above), Press the Diagnostic Tester “EXIT” button twice to bring up the OBD/MOBD Menu.
 - B. Follow the screen prints below.




Registration Procedure:
Smart Key/
Wireless
Function
(Continued)



Registration Procedure:
Smart Key/
Wireless Function
(Continued)

(Continued from previous page)



10. Confirm that Wireless and Smart functions are working properly.