



# Multiplex Communication System – Communication Bus





# Multiplex Communication System – Communication Bus

## Multiplex Communication System Includes Following Systems

- \* Automatic Light Control
- \* Door Lock Control
- \* Garage Door Opener
- \* Headlight
- \* Interior Light
- \* Key Reminder
- \* Light Auto Turn Off System
- \* Power Window
- \* Rear Wiper and Washer
- \* Seat Belt Warning
- \* Theft Deterrent
- \* Wireless Door Lock Control

### : Parts Location

Code	See Page	Code	See Page	Code	See Page
A28	<a href="#">38</a>	J37 B	<a href="#">46</a>	R10	<a href="#">41</a>
B3 A	<a href="#">38</a>	M8	<a href="#">44</a>	S28	<a href="#">45</a>
B4 B	<a href="#">38</a>	P7	<a href="#">44</a>	T5	<a href="#">41</a>
B5 C	<a href="#">38</a>	P8	<a href="#">44</a>	T6	<a href="#">41</a>
D18	<a href="#">42</a>	P9	<a href="#">44</a>	W4	<a href="#">41</a>
J36 A	<a href="#">46</a>	P20	<a href="#">46</a>		

### : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	<a href="#">30</a>	Instrument Panel Wire and J/B No.1 (Instrument Panel Reinforcement Left)
1B		
1C		
1D		

### : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	<a href="#">50</a>	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
ID1	<a href="#">50</a>	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
ID2		
IH1	<a href="#">52</a>	Instrument Panel Wire and Instrument Panel Wire (Near the J/B No.1)
IN1	<a href="#">54</a>	Floor No.3 Wire and Instrument Panel Wire (Under the Instrument Panel Brace RH)
IQ1	<a href="#">56</a>	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BC1	<a href="#">58</a>	Rear Door LH Wire and Instrument Panel Wire (Center Pillar LH)
BD1	<a href="#">58</a>	Rear Door RH Wire and Instrument Panel Wire (Center Pillar RH)

