



F RELAY LOCATIONS


[Engine Compartment]



[Instrument Panel]



[Body]




F RELAY LOCATIONS


② : Engine Room R/B

Engine Compartment Left (See Page 20)


- *1:ACC CUT Relay
- *2:FR FOG Relay
- *3:STA Relay
- *4:HEATER Relay
- *5:MG CLT Relay
- *6:ABS SOL Relay
- *7:C/OPN Relay
- *8:EFI Relay
- *9:DOME Relay
- *10:CDS FAN Relay
- *11:HEAD (LO LH)
- *12:HEAD (HI LH)
- *13:RADIO NO.1



③ : Engine Room R/B No.3	Engine Compartment Left (See Page 20)
--------------------------	---------------------------------------




④ : Engine Room R/B No.4	Engine Compartment Left (See Page 20)
--------------------------	---------------------------------------



F RELAY LOCATIONS

⑤ : Passenger Side R/B


[Right Kick Panel \(See Page 21\)](#)




F RELAY LOCATIONS

 : Driver Side J/B


Lower Finish Panel (See Page 21)





[Driver Side J/B Inner Circuit]







F RELAY LOCATIONS

○ : J/B No.1

Instrument Panel Reinforcement Left (See Page 21)




[J/B No.1 Inner Circuit]




F RELAY LOCATIONS

○ : J/B No.2

Instrument Panel Reinforcement Center (See Page 21)




[J/B No.2 Inner Circuit]



F RELAY LOCATIONS

○ : J/B No.3

Instrument Panel Reinforcement Right (See Page 21)



[J/B No.3 Inner Circuit]

