

INSTALLATION [10/2014 -]**CAUTION / NOTICE / HINT****HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure described below is for the LH side.

PROCEDURE**1. INSTALL CLEARANCE LIGHT ASSEMBLY LH**

- Attach the 2 claws to install the clearance light assembly LH.
- Install the 3 screws and clip.
- Attach the 2 wire harness clamps.
- w/ Headlight Cleaner System:
 - Attach the hose clamp.
 - Attach the claw to connect the headlight cleaner hose.

2. INSTALL FRONT BUMPER ASSEMBLY

except Sport Package:

Refer to INSTALLATION [10/2014 -]

for Sport Package:

Refer to INSTALLATION [10/2014 -]

3. INSPECT CLEARANCE LIGHT

- Turn the engine switch on (IG).
- Turn the headlight dimmer switch to the tail position and check that the clearance light illuminates.
- Turn the headlight dimmer switch to the AUTO and check that the day time running light illuminates.

HINT:

The day time running light illuminates when all of the following conditions are met.

- The headlight dimmer switch is turned to the AUTO position (and the low beam headlights are not turned on via the automatic light control system).
 - The ambient illuminance is determined to be daytime via the automatic light control sensor.
 - The parking brake is released.
- Turn the side turn signal switch left to right and check that the side turn signal light illuminates.