

REASSEMBLY [10/2014 -]

CAUTION / NOTICE / HINT

HINT:

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.


PROCEDURE


1. INSTALL NO. 1 MOULDING TAPE

- a. Clean the No. 1 moulding tape installation surface with a non-residue solvent.
- b. Apply primer to the No. 1 moulding tape installation area on the front fender moulding sub-assembly LH.

NOTE: *Apply primer evenly so that there are no uncoated areas.*

- c. Remove the peeling paper on a new No. 1 moulding tape while making sure not to touch the adhesional surface.
- d. Install a new No. 1 moulding tape in the position shown in the illustration.





Courtesy of © TOYOTA, LICENSE AGREEMENT TMS1002

*1	Mark-off Line
*a	3.0 mm (0.118 in.)
*b	1.5 mm (0.0591 in.)

NOTE:

a. Press the double-sided tape on the No. 1 moulding tape firmly to attach.


- b. After the primer dries (3 minutes or more), install the No. 1 moulding tape.
- c. After applying primer, reapply primer after 24 hours elapse.


2. INSTALL NO. 2 MOULDING TAPE

- a. Clean the No. 2 moulding tape installation surface with a non-residue solvent.
- b. Apply primer to the No. 2 moulding tape installation area on the front fender moulding sub-assembly LH.

NOTE: Apply primer evenly so that there are no uncoated areas.

- c. Remove the peeling paper on a new No. 2 moulding tape while making sure not to touch the adhesional surface.
- d. Install a new No. 2 moulding tape in the position shown in the illustration.





Courtesy of © TOYOTA, LICENSE AGREEMENT TMS1002

*1	Mark-off Line
*a	3.0 mm (0.118 in.)
*b	1.0 mm (0.0394 in.)

NOTE:

- Press the double-sided tape on the No. 2 moulding tape firmly to attach.
- After the primer dries (3 minutes or more), install the No. 2 moulding tape.
- After applying primer, reapply primer after 24 hours elapse.

